

# Field Temperature Block series

Beamex® FB150, FB350, FB660

## User Guide

**beamex**



---

## Table of Contents

<b>1</b>	<b>Before You Start .....</b>	<b>1</b>
1.1	Introduction.....	1
1.2	Unpacking .....	2
1.3	Symbols Used.....	3
1.4	Safety Information.....	4
1.4.1	Warnings .....	4
1.4.2	Cautions .....	6
1.5	CE Comments.....	7
1.5.1	EMC Directive .....	7
1.5.2	Immunity Testing .....	8
1.5.3	Emission Testing.....	8
1.5.4	Low Voltage Directive (Safety) .....	8
1.6	Authorized Service Centers.....	9
<b>2</b>	<b>Specifications and Environmental Conditions.....</b>	<b>11</b>
2.1	Specifications .....	11
2.2	Environmental Conditions .....	12
<b>3</b>	<b>Quick Start.....</b>	<b>13</b>
3.1	Setup.....	13
3.2	Parts and Controls .....	14
3.2.1	Display Panel .....	15
3.2.2	Display .....	16
3.2.3	Power Panel .....	17
3.2.4	-R Option Panel (-R models only).....	20
3.3	Languages.....	21
3.3.1	Language Selection .....	22
3.3.2	Reset to English Language .....	22
<b>4</b>	<b>Menu Structure.....</b>	<b>23</b>
4.1	Temp Setup Menu.....	23
4.2	Prog Menu .....	24
4.3	System Menu .....	25
4.4	Input Setup (-R only).....	26
<b>5</b>	<b>Controller operation.....</b>	<b>27</b>

5.1	Main Screen.....	27
5.2	Main Menu .....	28
5.2.1	Temp Setup .....	28
5.2.2	Prog Menu.....	30
5.2.3	System Menu.....	32
5.2.4	INPUT SETUP (-R model only) .....	38
<b>6</b>	<b>Digital communication interface.....</b>	<b>43</b>
6.1	Wiring.....	43
6.1.1	Setup .....	43
6.1.2	Serial Operation .....	43
6.2	Command Syntax .....	44
6.3	Commands by Function or Group .....	45
6.4	Serial Commands - Alphabetic Listing .....	48
6.5	Non-SCPI Process Commands.....	66
6.6	Non-SCPI Commands by Function or Group .....	66
<b>7</b>	<b>Troubleshooting .....</b>	<b>69</b>
<b>8</b>	<b>Maintenance .....</b>	<b>71</b>
8.1	Field Temperature Block Performance Analysis.....	71

---

## Tables

Table 1 Symbols used.....	3
Table 2 Base Unit Specifications .....	11
Table 3 -R Option Specifications .....	12
Table 4 Matching Certificate Values to ITS-90 Coefficients .....	39
Table 5 Setting Coefficients Rtpw, a8, b8, and b4.....	39
Table 6 Commands by Function or Group.....	45
Table 7 PROG:SEQ:PAR parameters.....	55
Table 8 Troubleshooting, problems, causes and solutions.....	69

**Figures**

Figure 1 Clamp-on ferrite installation ..... 8

Figure 2 FBXXX Field Temperature Block ..... 14

Figure 3 Display panel and keys ..... 16

Figure 4 FBXXX display ..... 17

Figure 5 FB150 power panel ..... 19

Figure 6 FB350 and FB660 power panel ..... 19

Figure 7 -R option panel ..... 20

Figure 8 Probe connector wiring ..... 21

Figure 9 Steps to language selection ..... 22

Figure 10 Main Menu - Temp SetUp ..... 23

Figure 11 Main Menu - Prog Menu ..... 24

Figure 12 Main Menu - System Menu ..... 25

Figure 13 Main Menu - Input Setup ..... 26

Figure 14 RS-232 wiring ..... 44

# 1 Before You Start

## 1.1 Introduction

Field Temperature Blocks (FB150, FB350, and FB660) are designed to be reliable, stable heat sources that can be used in the field or laboratory. They offer accuracy, portability, and speed for nearly every field calibration application. The instruments have been designed with the field user in mind and are easy to use while maintaining stability, uniformity, and accuracy comparable to some laboratory instruments.

Special built-in features make Field Temperature Blocks extremely adaptable. The exclusive Voltage Compensation allows the technician to plug into mains power with voltage from 90 V ac to 250 V ac without degradation to the instrument. The Ambient Temperature Compensation provides the largest operating range in the industry (0°C to 50°C) with the largest guaranteed temperature range (13°C to 33°C). The Gradient Temperature Compensation keeps the axial gradient within specification over the entire temperature range of the instrument and over the specified guaranteed operating temperature range. These combined features along with the rugged design, light weight, and small size make this line of instruments ideal for field applications.

Unique Patent Pending safety features make these the safest field heat sources available. The unique Air Flow Design keeps the probe handle cool protecting delicate instruments and the user. The Block Temperature Indicator shows the user when the well temperature is above 50°C letting the user know when it is safe to remove the insert or move the instrument. The indicator light illuminates when the instrument is energized and the well is above 50°C. If the instrument is removed from mains power, the indicator light flashes until the well has cooled to less than 50°C.

The optional “-R” version (“FBXXX-R”) combines the heat source with a built-in reference.

The Field Temperature Blocks’ controller uses a PRT sensor and thermoelectric modules or heaters to achieve stable, uniform temperatures throughout the block.

The LCD display continuously shows many useful operating parameters including the block temperature, the current set-point, block stability, and heating and cooling status. For the -R version, the reference temperature readings are displayed. The display can be set to show the information in one of eight different languages; English, Japanese, Chinese, German, Spanish, French, Russian, and Italian.

The instrument’s rugged design and special features make them ideal for the field or the laboratory. With proper use, the instrument provides continued accurate calibration of temperature sensors and devices. Before use, the user should be familiar with the warnings, cautions, and operating procedures of the block as described in the User’s Guide.

## 1.2 Unpacking

Unpack the instrument carefully and inspect it for any damage that may have occurred during shipment. If there is shipping damage, notify the carrier immediately.

Verify that the following components are present:

### **FB150**

- FB150 Field Temperature Block
- Insert: FB150-MH2, FB150-MH1, or FB150-B
- Power Cord
- RS-232 Cable
- User Guide
- Calibration Certificate and calibration label
- LEMO Connector (-R model only)
- Well Insulator
- Clamp-on ferrites (3) [-R model only]
- Tongs (insert removal tool)

### **FB350**

- FB350 Field Temperature Block
- Insert: FB350-MH2, FB350-MH1, or FB350-B
- Power Cord
- RS-232 Cable
- User Guide
- Calibration Certificate and calibration label
- LEMO Connector (-R model only)
- Clamp-on ferrites (3) (-R model only)
- Tongs (insert removal tool)

### **FB660**

- FB660 Field Temperature Block
- Insert: FB660-MH2, FB660-MH1, or FB660-B
- Power Cord
- RS-232 Cable
- User Guide
- Calibration Certificate and calibration label
- LEMO Connector (-R model only)
- Clamp-on ferrites (3) [-R model only]
- Tongs (insert removal tool)

If all items are not present, contact an Authorized Service Center (see Section 1.6 Authorized Service Centers on page 9).

### 1.3 Symbols Used

Table 1 lists the International Electrical Symbols. Some or all of these symbols may be used on the instrument or in this guide.

**Table 1** *Symbols used*

Symbol	Description
	AC (Alternating Current)
	AC-DC
	Battery
	Complies with European Union directives
	DC
	Double Insulated
	Electric Shock
	Fuse
	PE Ground
	Hot Surface (Burn Hazard)

Symbol	Description
	Read the User's Guide (Important Information)
	Off
	On
	Canadian Standards Association
	C-TICK Australian EMC mark
	The European Waste Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) mark.

---

## 1.4 Safety Information

Field Temperature Blocks are designed in accordance with IEC 61010-1, IEC 61010-2-010 and CAN/CSA 22.2 No 61010.1-04. Use this instrument only as specified in this manual. Otherwise, the protection provided by the instrument may be impaired. Refer to the safety information in the Warnings and Cautions sections below.

The following definitions apply to the terms “Warning” and “Caution”.

- “Warning” identifies conditions and actions that may pose hazards to the user.
- “Caution” identifies conditions and actions that may damage the instrument being used.

### 1.4.1 Warnings

To avoid personal injury, follow these guidelines.

#### GENERAL

**DO NOT** use this instrument in environments other than those listed in the User's Guide.

Inspect the instrument for damage before each use. Inspect the case. Look for cracks or missing plastic. **DO NOT** use the instrument if it appears damaged or operates abnormally.

Follow all safety guidelines listed in the User's Guide.

Calibration equipment should only be used by trained personnel.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Before initial use, or after transport, or after storage in humid or semi-humid environments, or anytime the instrument has not been energized for more than 10 days, the instrument needs to be energized for a "dry-out" period of 2 hours before it can be assumed to meet all of the safety requirements of the IEC 1010-2. If the product is wet or has been in a wet environment, take necessary measures to remove moisture prior to applying power such as storage in a low humidity temperature chamber operating at 50°C for 4 hours or more.

**DO NOT** use this instrument for any application other than calibration work. The instrument was designed for temperature calibration. Any other use of the instrument may cause unknown hazards to the user.

**DO NOT** place the instrument under a cabinet or other structure. Overhead clearance is required. Always leave enough clearance to allow for safe and easy insertion and removal of probes.

Use of this instrument at HIGH TEMPERATURES for extended periods of time requires caution.

Completely unattended high temperature operation is not recommended due to safety hazards that can arise.

This instrument is intended for indoor use only.

Follow all safety procedures for the test and calibration equipment you use.

Do not use the instrument if it operates abnormally. Protection may be impaired. When in doubt, have the instrument serviced.

**DO NOT** operate the Field Temperature Block around explosive gas, vapor, or dust.

**DO NOT** operate instrument at orientations other than upright. Tilting the instrument or laying it down on its side during use could create a fire hazard.

### **BURN HAZARD**

The instrument is equipped with a Block Temperature Indicator (front panel LED HOT indicator) even when the instrument is unplugged. When the indicator is flashing, the instrument is disconnected from mains power and the temperature of the block is above 50°C. When the indicator is illuminated, always on, the instrument is powered and the block temperature is above 50°C.

**DO NOT** turn the instrument upside down with the inserts in place; the inserts will fall out.

**DO NOT** operate near flammable materials.

Use of this instrument at HIGH TEMPERATURES for extended periods of time requires caution.

**DO NOT** touch the well access surface of the instrument.

The block vent may be very hot due to the fan blowing across the heater block of the instrument.

The temperature of the well access is the same as the actual display temperature, e.g. if the instrument is set to 600°C and the display reads 600°C, the well is at 600°C.

Probes and inserts may be hot and should only be inserted and removed from the instrument when the instrument indicates temperatures less than 50°C.

**DO NOT** turn off the instrument at temperatures higher than 100°C. This could create a hazardous situation. Select a set-point less than 100°C and allow the instrument to cool before turning it off.

The high temperatures present in Field Temperature Blocks designed for operation at 300°C and higher may result in fires and severe burns if safety precautions are not observed.

### **ELECTRICAL HAZARD**

These guidelines must be followed to ensure that the safety mechanisms in this instrument operate properly. This instrument must be plugged into an AC only electric outlet according to Table 2, Specifications . The power cord of the instrument is equipped with a grounding plug for your protection against electrical shock hazards. It must be plugged directly into a properly grounded receptacle. The receptacle must be installed in accordance with local codes and ordinances. Consult a qualified electrician. **DO NOT** use an extension cord or adapter plug.

If supplied with user accessible fuses, always replace the fuse with one of the same rating, voltage, and type.

Always replace the power cord with an approved cord of the correct rating and type.

HIGH VOLTAGE is used in the operation of this equipment. SEVERE INJURY or DEATH may result if personnel fail to observe safety precautions. Before working inside the equipment, turn power off and disconnect power cord.

#### **1.4.2 Cautions**

To avoid possible damage to the instrument, follow these guidelines:

**DO NOT** leave the inserts in the instrument for prolonged periods. Due to the high operating temperatures of the instrument, the inserts should be removed after each use and buffed with a Scotch-Brite® pad or emery cloth (see Section 8 Maintenance on page 71).

Always operate this instrument at room temperature between 5°C and 50°C (41°F to 122°F). Allow sufficient air circulation by leaving at least 15 cm (6 in) of clearance

around the instrument. Overhead clearance of 1 meter (3 ft) is required. **DO NOT** place instrument under any structure.

Component lifetime can be shortened by continuous high temperature operation.

**DO NOT** use fluids to clean out the well. Fluids could leak into electronics and damage the instrument.

Never introduce any foreign material into the probe hole of the insert. Fluids, etc. can leak into the instrument causing damage.

Unless recalibrating the instrument **DO NOT** change the values of the calibration constants from the factory set values. The correct setting of these parameters is important to the safety and proper operation of the block.

**DO NOT** allow the probe sheath or inserts to drop into the well. This type of action can cause a shock to the sensor and affect the calibration.

The instrument and any thermometer probes used with it are sensitive instruments that can be easily damaged. Always handle these devices with care. **DO NOT** allow them to be dropped, struck, stressed, or overheated.

**DO NOT** operate this instrument in an excessively wet, oily, dusty, or dirty environment. Always keep the well and inserts clean and clear of foreign material.

The Field Temperature Block is a precision instrument. Although it has been designed for optimum durability and trouble free operation, it must be handled with care. Always carry the instrument in an upright position to prevent the inserts from dropping out. The convenient handle allows for hand carrying the instrument.

If a mains supply power fluctuation occurs, immediately turn off the instrument. Power bumps from brown-outs could damage the instrument. Wait until the power has stabilized before re-energizing the instrument.

The probe and the block may expand at different rates. Allow for probe expansion inside the well as the block heats. Otherwise, the probe may become stuck in the well.

Most probes have handle temperature limits. If the probe handle limits are exceeded, the probe may be permanently damaged. Due to a unique Air Flow Design, Field Temperature Blocks protect the probe handle temperature and provide a safer temperature handle for the user.

## **1.5 CE Comments**

### **1.5.1 EMC Directive**

Beamex equipment has been tested to meet the European Electromagnetic Compatibility Directive (EMC Directive, 89/336/EEC). The Declaration of Conformity for your instrument lists the specific standards to which the instrument was tested.

The instrument was designed specifically as a test and measuring device. Compliance to the EMC directive is through IEC 61326-1 Electrical equipment for measurement, control and laboratory use.


As noted in the IEC 61326-1, the instrument can have varying configurations. The instrument was tested in a typical configuration with shielded RS-232 cables.

## 1.5.2 Immunity Testing

### Using Clamp-On Ferrites

For the -R model only, clamp-on ferrites are provided for use in improving its electromagnetic (EM) immunity in environments of excessive EM interference. During EMC testing we found that ferrites clamped around probe cables for the Reference PRT input reduced the risk the EM interference affects measurements. Therefore, we recommend that the clamp-on ferrites provided be used on the cables of probes attached to the readout, especially if the product is used near sources of EM interference such as heavy industrial equipment.

To attach a ferrite to a probe cable, make a loop in the cable near the connector and clamp the ferrite around half of the loop as shown in the diagram. The ferrite can be easily snapped open and moved to a new probe when needed.



*Figure 1* Clamp-on ferrite installation

## 1.5.3 Emission Testing

The instrument fulfills the limit requirements for Class A equipment. The instrument was not designed to be used in domestic establishments.

## 1.5.4 Low Voltage Directive (Safety)

In order to comply with the European Low Voltage Directive (2006/95/EC), Bea-mex equipment has been designed to meet the EN 61010-1 and the EN 61010-2-010 standards.

## 1.6 Authorized Service Centers

Please contact the following Authorized Service Center to coordinate service on your Beamex product:

**Beamex Oy Ab**  
Ristisuonraitti 10  
FI-68600 Pietarsaari  
Finland

When contacting a Service Centers for support, please have the following information available:

- Model Number
- Serial Number
- Voltage
- Complete description of the problem



## 2 Specifications and Environmental Conditions

### 2.1 Specifications

*Table 2 Base Unit Specifications*

<b>Base Unit Specifications</b>			
	<b>FB150</b>	<b>FB350</b>	<b>FB660</b>
<b>Temperature Range at 23 °C</b>	-25 °C to 150 °C (-13 °F to 302 °F)	33 °C to 350 °C (91 °F to 662 °F)	50 °C to 660 °C (122 °F to 1220 °F)
<b>Display Accuracy</b>	± 0.2 °C Full Range	± 0.2 °C Full Range	± 0.35 °C at 50 °C ± 0.35 °C at 420 °C ± 0.5 °C at 660 °C
<b>Stability</b>	± 0.01 °C Full Range	± 0.02 °C at 33 °C ± 0.02 °C at 200 °C ± 0.03 °C at 350 °C	± 0.03 °C at 50 °C ± 0.05 °C at 420 °C ± 0.05 °C at 660 °C
<b>Axial Uniformity at 40 mm (1.6 in)</b>	± 0.05 °C Full Range	± 0.04 °C at 33 °C ± 0.1 °C at 200 °C ± 0.2 °C at 350 °C	± 0.05 °C at 50 °C ± 0.35 °C at 420 °C ± 0.5 °C at 660 °C
<b>Axial Uniformity at 60 mm (2.4 in)</b>	± 0.07 °C Full Range	± 0.04 °C at 33 °C ± 0.2 °C at 200 °C ± 0.25 °C at 350 °C	± 0.1 °C at 50 °C ± 0.6 °C at 420 °C ± 0.8 °C at 660 °C
<b>Radial Uniformity</b>	± 0.01 °C Full Range	± 0.01 °C at 33 °C ± 0.015 °C at 200 °C ± 0.02 °C at 350 °C	± 0.02 °C at 50 °C ± 0.05 °C at 420 °C ± 0.1 °C at 660 °C
<b>Loading Effect (with a 6.35 mm reference probe and three 6.35 mm probes)</b>	± 0.006 °C Full Range	± 0.015 °C Full Range	± 0.015 °C at 50 °C ± 0.025 °C at 420 °C ± 0.035 °C at 660 °C
<b>Loading Effect (versus display with 6.35 mm probes)</b>	± 0.08 °C Full Range	± 0.2 °C Full Range	± 0.1 °C at 50 °C ± 0.2 °C at 420 °C ± 0.2 °C at 660 °C
<b>Hysteresis</b>	0.025 °C	0.06 °C	0.2 °C
<b>Operating Conditions</b>	0 °C to 50 °C, 0 % to 90 % RH (non-condensing)		
<b>Environmental conditions for all specifications except temperature range</b>	13 °C to 33 °C		
<b>Immersion (Well) Depth</b>	150 mm (5.9 in)		
<b>Insert OD</b>	30 mm (1.18 in)	25.3 mm (1.00 in)	24.4 mm (0.96 in)
<b>Heating Time</b>	16 min: 23 °C to 140 °C 23 min: 23 °C to 150 °C 25 min: -25 °C to 150 °C	5 min: 33 °C to 350 °C	15 min: 50 °C to 660 °C
<b>Cooling Time</b>	15 min: 23 °C to -25 °C 25 min: 150 °C to -23 °C	32 min: 350 °C to 33 °C 14 min: 350 °C to 100 °C	35 min: 660 °C to 50 °C 25 min: 660 °C to 100 °C
<b>Resolution</b>	0.01 °		
<b>Display</b>	LCD, °C or °F user-selectable		
<b>Key Pad</b>	Arrows, Menu, Enter, Exit, 4 soft keys		
<b>Size (H x W x D)</b>	290 mm x 185 mm x 295 mm (11.4 x 7.3 x 11.6 in)		

## FBXXX Field Temperature Block

### Environmental Conditions

<b>Base Unit Specifications</b>			
	<b>FB150</b>	<b>FB350</b>	<b>FB660</b>
<b>Weight</b>	8.16 kg (18 lbs)	7.3 kg (16 lbs)	7.7 kg (17 lbs)
<b>Power Requirements</b>	100 V to 115 V ( $\pm 10\%$ ) 50/60 Hz, 575 W 230 V ( $\pm 10\%$ ) 50/60 Hz, 575 W	100 V to 115 V ( $\pm 10\%$ ), 50/60 Hz, 1400 W 230 V ( $\pm 10\%$ ), 50/60 Hz, 1800 W	
<b>System Fuse Ratings</b>	115 V: 6.3 A T 250 V 230 V: 3.15 A T 250 V	15 A, 250 V Thermal Circuit Breakers	
<b>Computer Interface</b>	RS-232		
<b>Safety</b>	EN 61010-1:2001, CAN/CSA C22.2 No. 61010.1-04		

Table 3 -R Option Specifications

<b>-R Specifications</b>	
<b>Built-in Reference Thermometer Readout Accuracy (4-Wire Reference Probe)<sup>†</sup></b>	$\pm 0.013\text{ }^{\circ}\text{C}$ at $-25\text{ }^{\circ}\text{C}$ $\pm 0.015\text{ }^{\circ}\text{C}$ at $0\text{ }^{\circ}\text{C}$ $\pm 0.020\text{ }^{\circ}\text{C}$ at $50\text{ }^{\circ}\text{C}$ $\pm 0.025\text{ }^{\circ}\text{C}$ at $150\text{ }^{\circ}\text{C}$ $\pm 0.030\text{ }^{\circ}\text{C}$ at $200\text{ }^{\circ}\text{C}$ $\pm 0.040\text{ }^{\circ}\text{C}$ at $350\text{ }^{\circ}\text{C}$ $\pm 0.050\text{ }^{\circ}\text{C}$ at $420\text{ }^{\circ}\text{C}$ $\pm 0.070\text{ }^{\circ}\text{C}$ at $660\text{ }^{\circ}\text{C}$
<b>Reference Resistance Range</b>	0 ohms to 400 ohms
<b>Reference Resistance Accuracy<sup>‡</sup></b>	0 ohms to 42 ohms: $\pm 0.0025$ ohms 42 ohms to 400 ohms: $\pm 60$ ppm of reading
<b>Reference Characterizations</b>	ITS-90, CVD, IEC-60751, Resistance
<b>Reference Measurement Capability</b>	4-wire
<sup>†</sup> The temperature range may be limited by the reference probe connected to the readout. The Built-In Reference Accuracy does not include the sensor probe accuracy. It does not include the probe uncertainty or probe characterization errors. <sup>‡</sup> Measurement accuracy specifications apply within the operating range and assume 4-wires for PRTs.	

## 2.2 Environmental Conditions

Although the instrument has been designed for optimum durability and trouble-free operation, it must be handled with care. The instrument should not be operated in an excessively dusty or dirty environment. Maintenance and cleaning recommendations can be found in the Maintenance section. The instrument operates safely under the following environmental conditions:

- ambient temperature range:  $0\text{-}50^{\circ}\text{C}$  ( $32\text{-}122^{\circ}\text{F}$ )
- ambient relative humidity: 0 % to 90 % (non-condensing)
- mains voltage: within  $\pm 10\%$  of nominal
- vibrations in the calibration environment should be minimized
- altitude: less than 2,000 meters
- indoor use only

## 3 Quick Start

### 3.1 Setup



*Note: The instrument will not heat, cool, or control until the “SET PT.” parameter is “Enabled”.*

Place the block on a flat surface with at least 15 cm (6 in) of free space around the instrument. Overhead clearance is required. DO NOT place under a cabinet or structure.

Plug the instrument power cord into a mains outlet of the proper voltage, frequency, and current capability (see Section 2.1, Specifications, on page 11 for power details). Observe that the nominal voltage corresponds to that indicated on the front of the block.

Carefully place the insert into the well. Inserts should be of the smallest hole diameter possible still allowing the probe to slide in and out easily. Various insert sizes are available. Contact an Authorized Service Center for assistance (see Section 1.6, Authorized Service Centers, on page 9). The well must be clear of any foreign objects, dirt and grit before an insert is installed. The insert is installed with the two small tong holes positioned upward.

Turn on the power to the block by toggling the switch on the power entry module. After a brief self-test, the controller should begin normal operation. The main screen appears within 30 seconds. If the instrument fails to operate, please check the power connection. The display shows the well temperature, and waits for user input before further operation.

Press “SET PT.” and use the arrow keys to set the desired set-point temperature. Press “ENTER” to save the desired set-point and enable the instrument. After five (5) seconds, the instrument should start to operate normally and heat or cool to the designated set-point.

# FBXXX Field Temperature Block

## Parts and Controls



Figure 2 FBXXX Field Temperature Block

### 3.2 Parts and Controls

This section describes the exterior features of the Field Temperature Block. All interface and power connections are found on the front of the instrument (see Figure 2).

### **3.2.1 Display Panel**

Figure 3 on next page shows the layout of the display panel.

#### **Display (1)**

The display is a 240 x 160 pixel monochrome graphics LCD device with a bright LED backlight. The display is used to show current control temperature, measurements, status information, operating parameters, and soft key functions.

#### **▲▼◀▶ Arrow Keys (2)**

The Arrow Keys allow you to move the cursor on the display, change the display layout, and adjust the contrast of the display. The contrast can only be adjusted using the ▲ and ▼ arrow keys while viewing the main display window.

#### **Enter Key (3)**

The Enter Key allows you to select menus and accept new values.

#### **SET PT. (4)**

The Set Pt. Key allows you to enable the instrument to heat or cool to a desired set-point. Until this key is enabled, the instrument will not heat or cool. It is in a “sleep” state for safety of the operator and instrument.

#### **°C/°F Key (5)**

The °C/°F Key allows you to change the displayed temperature units from °C to °F and vice versa.

#### **Menu Key (6)**

The Menu Key allows the user to access all parameter and settings menus. From the main menu, the user can use the soft keys to access submenus and functions.

#### **Exit Key (7)**

The Exit Key allows you to exit menus and cancel newly entered values.

#### **Soft Keys (8)**

The Soft Keys are the four buttons immediately below the display (labeled F1 to F4). The functions of the soft keys are indicated on the display above the buttons. The function of the keys may change depending on the menu or function that is selected.

### Block Temperature Indicator (9)

The Block Temperature Indicator lamp allows users to know when the block temperature is safe (50°C to 60°C) to remove inserts or move the Field Temperature Block. The indicator light is lit continuously once the block has exceeded approximately 50°C (varies 50°C to 60°C). The indicator light stays lit until the block cools to less than approximately 50°C. If the instrument is disconnected from mains power, the indicator light flashes until the block temperature is less than approximately 50°C.



Figure 3 Display panel and keys

### 3.2.2 Display

The front panel display is shown in detail in Figure 4 on opposite page.

#### Heat Source Temperature (1)

The most recent block temperature measurement is shown in large digits in the box at the top of the screen.

#### Set-point Temperature (2)

The current set-point temperature is displayed just below the Process Temperature.

#### Reference Thermometer Temperature (3) [-R models only]

When installed, the most recent reference thermometer measurement is shown on the screen.

### Stability Status (4)

On the right hand side of the screen, you will find a graph displaying the current status of the stability of the Field Temperature Block.

### Heating/Cooling Status (5)

Just below the stability graph there is a bar graph that will indicate HEATING, COOLING, or CUTOUT. This status graph indicates the current level of heating or cooling if the instrument is not in cutout mode.

### Soft Key Functions (6)

The four texts at the bottom of the display (not shown) indicate the functions of the soft keys (F1–F4). These functions change with each menu.

### Editing Windows

While setting up and operating the instrument, you are often required to enter or select parameters. Editing windows appear on the screen when necessary to show the values of parameters and allow edits.




Figure 4 FBXXX display

### 3.2.3 Power Panel

The following are found on the lower front panel of the instrument (see Figures 5 and Figure 6 on page 19).

**Power Cord Plug (1)**

The power supply cord attaches to the lower front power panel. Plug the cord into an AC mains supply appropriate for the voltage range as specified in the specifications tables.

**Power Switch (2)**

For the FB150, the power switch is located on the power entry module of the unit at the lower center of the power panel.

For the FB350 and FB660, the power switch is located between the RS-232 and the circuit breakers.

**Serial Connector (3)**

On the FB150, the serial connector is a 9-pin subminiature D type located on the power panel above the power entry module. On the FB350 and FB660, the serial connector is a 9-pin subminiature D type located on the power panel to the left of the power switch. The serial (RS-232) interface can be used to transmit measurements and control the operation of the instrument.

**Fuses**

For the FB150, the fuses are located inside the power entry module of the unit (Figure 5 on opposite page).

If necessary, fuses must be replaced according to Specifications (see Section 2.1, Specifications, on page 11).

**Thermal Circuit Breakers (5)**

For the FB350 and FB660, the thermal circuit breakers are separate from the power connector (Figure 6 on opposite page). Circuit breakers can be reset by pressing the button in the center of each circuit breaker.




Figure 5 FB150 power panel





Figure 6 FB350 and FB660 power panel

### 3.2.4 -R Option Panel (-R models only)

The -R (reference sensor) panel is the readout portion of the instrument and is only available with -R models.




*Figure 7 -R option panel*

#### **Reference Thermometer Connection (1)**

The 6-pin Lemo smart connector on the front panel allows a reference probe to be attached to the instrument for use with the reference thermometer function of the instrument. The smart connector stores probe calibration coefficients. Using an adapter, the 6-pin Lemo will accept traditional connectors and the probe coefficients can be entered into the readout or an appropriate characterization curve can be selected through the user interface (see Section 1.5.2, Immunity Testing, on page 8 for information on using clamp-on ferrites).

A PRT is the only type of probe that is supported by the reference thermometer input. The PRT (RTD or SPRT) probe connects to the reference thermometer input using a 6-pin Lemo connector. Figure 8 shows how a four-wire probe is wired to the 6-pin Lemo connector. One pair of wires attaches to pins 1 and 2 and the other pair attaches to pins 4 and 5 (pins 1 and 5 source current and pins 2 and 4 sense the potential). If a shield wire is present, it should be connected to pin 3, which is also used for the memory circuit. Pin 6 is only used for the memory circuit.



**Figure 8** Probe connector wiring

A two-wire probe can also be used with the reference thermometer. It is connected by attaching one wire to both pins 1 and 2 of the plug and the other wire to both pins 4 and 5. If a shield wire is present, it should be connected to pin 3. Accuracy may be significantly degraded using a two-wire connection because of lead resistance.


### 3.3 Languages

The display on Field Temperature Blocks can be set to different languages depending on the configuration.

- European: English, French, Spanish, Italian, German
- Russian: Russian, English
- Asian: English, Chinese, Japanese

#### 3.3.1 Language Selection

Select the language to be displayed by following the steps shown in Figure 9 on this page.



*Figure 9 Steps to language selection*

#### 3.3.2 Reset to English Language

If you are in a language and need a short cut exit, press F1 and F4 simultaneously to reset the display to English.


To reset to your originally selected language after resetting to English, follow the steps in Figure 9 on this page.



**Note:** The F1 and F4 English shortcut override is temporary. If you toggle the power off, the instrument will return to the language selected in the DISPLAY SETUP menu rather than coming up in English.

## 4 Menu Structure

### 4.1 Temp Setup Menu



#### **Hot Keys (while viewing main screen)**

##### SETPoinT- Set Point Key

Setpoint: <Edit> Set point temperature  
 ENTER – <Enable control of the unit>  
 F1 – SELECT PRESET <1-8> <select>  
     F1 – EDIT PRESETS <1-8> <edit>  
 F4 – SAVE/DISABLE System <disables control of instrument>

°C / °F Key -      Units: <°C, °F> Changes temperature units

Up/ Down Arrow Keys <toggle> <adjust contrast>

Up Key:   Darker  
 Down Key: Lighter

F1 & F4 Keys (Same Time) < Reset to English Language >


F1 & F3 Keys (Same Time) < Turn off key press beep >

#### **Code Update Mode Keys**

ENTER & EXIT Keys (hold during power up) <initiate code update mode> Allows instrument software to be updated

**Figure 10** Main Menu - Temp SetUp

## 4.2 Prog Menu



**Figure 11** Main Menu - Prog Menu

## 4.3 System Menu





Figure 12 Main Menu - System Menu

## 4.4 Input Setup (-R only)



**Figure 13** Main Menu - Input Setup

## **5 Controller operation**

This chapter discusses in detail how to operate the Field Temperature Block temperature controller and/or thermometer readout using the front control panel. Using the front panel keys and liquid crystal display (LCD) the user may monitor the well temperature, set the temperature set-point in °C or °F, monitor the heater output power, monitor the stability, set the cutout set-point, set the operating parameters, and configure the communication interface. For the -R model, the user has full control of thermometer readout functions of the instrument using the front panel keys and the LCD. A diagram of the full menu structure can be found in Section 4, Menu Structure, on page 23. When active, menu keys are selected using the soft keys (F1-F4).

### **5.1 Main Screen**

The LCD on the front panel allows direct viewing of the control temperature (actual well temperature), reference thermometer temperature (-R model only), heating or cooling power, stability state, current set-point information, and current program information. The temperature displayed is either in °C or °F. The displayed temperature units can easily be changed by pressing the C/F key on the front panel.

#### **HEAT SOURCE TEMPERATURE**

This is the temperature of the block as measured by the control sensor. The controller heats or cools the block to force the control temperature equal to the set-point.

#### **SET-POINT (SETPT)**

This is the current set-point.

#### **REFERENCE TEMPERATURE (REF) (-R model only)**

This is the temperature measured by an external reference thermometer attached to the Reference Thermometer 6-pin Smart Lemo input.

#### **CONTROL - STAB (Stability)**

This shows the stability of the block. When the stability is within the set limit this line is flat.

#### **CONTROL - HEAT/COOL**

This shows the relative heating or cooling power (duty cycle) in percent.

#### **HEATING, COOLING, CUTOUT**

This shows the status of heating or cooling or the cutout when activated. The bar graph indicates the relative heating or cooling power.

## 5.2 Main Menu

The MAIN MENU is accessed through the MENU button and allows access to all main submenus. The submenus allow the user to setup the instrument as desired and to change system parameters as needed.

### 5.2.1 Temp Setup

The TEMP SETUP menu contains Field Temperature Block functions related to temperature setup.

#### 5.2.1.1 Setup

##### 5.2.1.1.1 SCAN RATE

The SCAN RATE parameter can be set such that when the set-point is changed, the Field Temperature Block heats or cools at a specified rate, degrees per minute, ( $^{\circ}\text{C}/\text{min}$  or  $^{\circ}\text{F}/\text{min}$ ) until it reaches the new set-point.

The Scan Rate can be set from 0.1 to 500  $^{\circ}\text{C}/\text{min}$  (0.2 to 900  $^{\circ}\text{F}/\text{min}$ ). However, the maximum scan rate is limited by the natural heating or cooling rate of the instrument, which will be less than the maximum setting, especially when cooling.

The Scan Rate can be adjusted using the arrow keys. Once the scan rate has been set, press “ENTER” to set the new scan rate.

##### 5.2.1.1.2 STABLE LIMIT



**NOTE:** *The Field Temperature Block should not be expected to operate better than the stability specification set forth in the Specifications section of this guide. Therefore, the minimum setting of the stability limit should not be less than the stability specification.*

The STABLE LIMIT parameter allows the instrument to notify the user when it has achieved the stability limit set in this parameter. There are two notifications: visual and audible. The visual notification is always active. When the instrument is operating within the stability limit, the stability graph on the main screen remains flat once the instrument is within the given specification, otherwise the graph indicates the instrument is not yet stable. The audible, if enabled, alerts the user once per set-point when the instrument achieves the set stability limit. Use the arrow keys to set the desired stability limit and press “ENTER” to accept the new stability limit.

Example:

A specific calibration process requires the instrument to operate within  $\pm 0.1^{\circ}\text{C}$ . “0.1” would be entered into the stability limit parameter. When the instrument’s stability is within  $\pm 0.1^{\circ}\text{C}$ , the graph is flat and the audible alarm (if enabled) notifies the user that the instrument is operating within  $\pm 0.1^{\circ}\text{C}$ . Use the arrow keys to set the desired stability limit and press “ENTER” to accept the new stability limit.

### 5.2.1.1.3 STABLE ALARM

The audible alarm described in STABLE LIMIT is turned on or off using the STABLE ALARM parameter. Select the either “Enable” or “Disable” using the left or right arrow keys and press “ENTER” to accept the selection.

### 5.2.1.2 CUTOUT

The view CUTOUT contains the Cutout functions of the instrument.

#### 5.2.1.2.1 SOFT CUTOUT

The SOFT CUTOUT is user settable. As a protection against software or hardware fault or user error, the block is equipped with the adjustable cutout device that shuts off power to the heat source if the well temperature exceeds a set value. It is factory set as a default ten degrees above the high limit of the instrument. The user should set the Soft Cutout according to the temperature limits of the probes being calibrated. The Soft Cutout can act as a safety barrier to protect probes from being over heated to temperatures beyond their specified temperature limits if the Soft Cutout is set appropriately for probes under test. This feature protects the instrument and probes from excessive temperatures.

If the cutout is activated because of excessive well temperature, power to the heat source shuts off and the instrument cools. The heat source remains in cutout mode and active heating and cooling is disabled until the user manually resets the cutout. If the over-temperature cutout has been triggered, the instrument displays “CUTOUT” above the duty cycle bar graph, which indicates a cutout condition. The instrument remains in cutout mode until the temperature is reduced and the cutout is reset. The well temperature must drop a few degrees below the cutout set-point before the cutout can be reset.

For safety reasons, the cutout only has one mode — manual reset. Manual reset mode means the cutout must be reset by the operator after the temperature falls below the set-point.

The SOFT CUTOUT parameter can be set to any temperature over the range of the instrument. The cutout should be set within 5-10° of the safety limit of the equipment being calibrated or used with the Field Temperature Block.



**NOTE:** *CUTOUT RESET: If the Field Temperature Block exceeds the temperature set in the soft cutout menu or if it exceeds the maximum operating temperature of the instrument, a cutout condition occurs. If this happens, the instrument enters cutout mode and will not actively heat or cool until the user resets the instrument.*

To reset the cutout, the instrument temperature must cool to lower than the cutout set-point. Once the instrument has cooled the user may reset the instrument by pressing “SET PT.” and pressing “ENTER” to engage instrument.

### **5.2.1.2.2 HARD CUTOUT**

The HARD CUTOUT parameter is a view only function and indicates the factory setting for the hard cutout. The Hard Cutout is not user settable.

## **5.2.2 Prog Menu**

The PROG MENU (PROGRAM MENU) allows access to the automated and manual program selections.

### **5.2.2.1 RUN PROG**

The RUN PROG (RUN PROGRAM) allows the user to access program status features.

#### **5.2.2.1.1 TEST STATUS**

The TEST STATUS option controls the state of the program. The user selects to Run the program or to turn the program Off.

#### **5.2.2.1.2 RECORD DATA**

The RECORD DATA option allows the user to select to record the data from the test (Yes) or not to record data (No).

#### **5.2.2.1.3 TEST ID**

The TEST ID (Identification) allows the user to enter a Test ID number for the current test. The Test ID can be an alpha numeric entry up to 16 characters in length.

### **5.2.2.2 RAMP/SOAK**

The RAMP/SOAK feature automatically cycles the Field Temperature Block between temperatures while holding at each temperature for the length of time set by the user.

#### **5.2.2.2.1 NO. SETPOINTS**

The NO. SETPOINTS is the number of set-points defined for a given program. The number of set-points for each program can be set from 1 to 8 and vary depending on the needs of the user. Set the maximum number of set-points needed for the program selected. Once the number of set-points is selected, press “ENTER” to accept the new setting.

#### **5.2.2.2.2 SOAK TIME**

The SOAK TIME parameter is the number of minutes that each of the program set-points is maintained. The time starts when the temperature settles to within the specified stability. The stability limit is set in the TEMP SETUP|SETUP|STABLE LIMIT window.

**5.2.2.2.3 NO. CYCLES**

The NO. CYCLES parameter is the number of times that the program is repeated.

**5.2.2.2.4 DIRECTION**

The DIRECTION parameter controls whether the set-points are sequenced in one direction, 1-8, or both directions, 1-8 and 8-1, before the sequence is repeated. If the both directions option is selected, the program sequences from the first set-point to the last and then reverses direction sequencing from the last to the first.

**5.2.2.2.5 PASS TOLERANCE**

The PASS TOLERANCE is the allowable tolerance condition for the test and is used to highlight test points that have large errors.

**5.2.2.2.6 SETPOINTS**

The SETPOINTS menu allows the user to set each of the set-points for the program. Only the number of set-points defined by NO SETPOINTS will be displayed. Set-points can be quickly selected using the Up/Down arrow keys to scroll through the set-points. Press "Enter" to activate the set-point and make it editable. Once editable, use the Up/Down arrow keys to enter the values and the Left/Right arrow keys to scroll through the digits in the value. Press "Enter" to accept the value entered.

*5.2.2.2.6.1 SETPOINT 1 – SETPOINT 8 (Depending on NO. SETPOINTS defined)*

The SETPOINT n parameter is the designated temperatures for the set-points selected for the program.

**5.2.2.3 TEST RESULTS**

The TEST RESULTS MENU allows the user access to the tests parameters.

**5.2.2.3.1 VIEW TESTS**

The VIEW TESTS menu allows the user to view the results of up to 16 tests.

*5.2.2.3.1.1 TEST ID*

The TEST ID (TEST IDENTIFICATION) parameter allows the user to select from 16 tests to view.

*5.2.2.3.1.2 TYPE*

The TYPE parameter allows the user to select between viewing Ramp & Soak results.

*5.2.2.3.1.3 DATE (VIEW ONLY)*

The DATE the selected test was performed.

#### 5.2.2.3.1.4 *TIME (VIEW ONLY)*

The TIME the selected test was performed.

#### 5.2.2.3.1.5 *RESULTS (press ENTER)*

The RESULTS menu is the second part of the VIEW TESTS menu and allows the user to view the results of the selected test.

#### 5.2.2.3.1.5.1 RAMP & SOAK

##### 5.2.2.3.1.5.1.1 TEST ID

The TEST ID (TEST IDENTIFICATION) parameter allows the user to select from 16 tests to view.

##### 5.2.2.3.1.5.1.2 WELL

The WELL (WELL TEMPERATURE) result provides the temperature of the dry-well as measured by the control sensor.

##### 5.2.2.3.1.5.1.3 REF

The REF (REFERENCE) result provides the temperature of the reference probe.

#### **5.2.2.3.2 PRINT TESTS**

The PRINT TESTS parameter allows the user to the option to print the selected test results. YES enables the print option. NO disables the print option.

#### **5.2.2.3.3 ERASE TESTS**

The ERASE TESTS option is unconditionally password protected. The user has the choice, YES/NO, to erase all of the stored tests. A warning is presented to the user stating that all tests will be erased.

### **5.2.3 System Menu**

The System Menu allows the user to set up the display settings, communications protocol, date/time settings (-R model only), password settings, calibrations settings, and view system information.

#### **5.2.3.1 SYSTEM SETUP**

The SYSTEM SETUP menu contains the Display Setup, Communications Setup, and Date/Time Setup (-R model only).

### 5.2.3.1.1 DISPLY SETUP

The DISPLY SETUP (DISPLAY SETUP) parameter contains the language selection, decimal separator, and keypad sound parameters.

#### 5.2.3.1.1.1 LANGUAGE

The LANGUAGE parameter is used to set the display language. Use the right or left arrow key to select the preferred language and press “ENTER” to accept the selection. The user needs to exit from the SYSTEM MENU window in order for the change in language selection to take affect.



**NOTE:** *If the wrong language is selected, return to the Main Screen by holding EXIT for a few seconds. Once the Main Screen is displayed, simultaneously press and hold F1 and F4 to set to English temporarily. Then return to the DISPLAY SETUP screen and set the correct language.*

#### 5.2.3.1.1.2 DECIMAL

The DECIMAL parameter is used to determine the decimal separator, a comma or a period. Select the desired decimal separator using the right or left arrow key and press “ENTER” to accept the selection.

#### 5.2.3.1.1.3 KEY AUDIO

The KEY AUDIO parameter (F1 and F3 Keys pressed simultaneously) enables or disables the key press beep.

### 5.2.3.1.2 COMM SETUP

The COMM SETUP (COMMUNICATIONS SETUP) menu contains the serial interface parameters. The parameters in the menu are—BAUD RATE and LINEFEED.

#### 5.2.3.1.2.1 BAUD RATE

The BAUD RATE parameter determines the serial communication transmission rate or baud rate.

BAUD may be programmed to 1200, 2400, 4800, 9600, 19200, or 38400 baud.

#### 5.2.3.1.2.2 LINEFEED

The LINEFEED enables (On) or disables (Off) transmission of a line feed character (LF, ASCII 10) after transmission of any carriage-return. The LINEFEED default setting is on. The line feed parameter can be turned on or off as needed by the user.

### **5.2.3.1.3 DATE TIME (-R model only)**

The DATE TIME menu allows the user to set the format for the date and time. Additionally, the user sets the date and time for the date and time stamp function.

#### *5.2.3.1.3.1 TIME*

The TIME parameter allows the user to set the internal time for the instrument. The time is tracked using a 24-hour clock. To set the time, press “Enter” and use the arrow keys to set the time and press “Enter” to accept the selection.

#### *5.2.3.1.3.2 DATE*

The DATE parameter allows the user to enter the date for the date/time stamp function. Press “Enter” to access the parameter. Use the arrow keys to enter the date and press “Enter” to accept the selection.

#### *5.2.3.1.3.3 REPORT DATES*

The REPORT DATES parameter allows the user to select the date format. Use the left and right arrow keys to choose the date format, mm/dd/yyyy or dd/mm/yyyy, and press “Enter” to accept the selection.

### **5.2.3.2 PASSWORD**

The PASSWORD (PASSWORD SETUP) menu is used to set the system password or set the level of protection that conditionally engages or disengages protection of certain groups of parameters.

#### **5.2.3.2.1 USER PASSWORD**

The USER PASSWORD parameter allows the users to enter and change the system and conditional password used to access protected menus. The Password is a number between one and four digits. Each digit of the password can be a number from 0 to 9. The default System Password is “1234”. If desired, the System Password can be changed in this menu by using the numeric keys to enter the new password and pressing “ENTER”.

#### **5.2.3.2.2 PROTECTION**

The PROTECTION parameter is used to enable (HIGH) or disable (LOW) password protection for the conditional parameters. The password is the same as the system password. The user has to option to conditionally password protect the Soft Cutout, Ramp & Soak, and Probe Prog. The user selects to “HIGH” or “LOW” the conditional password using the left and right arrow keys and presses “Enter” to accept the selection.

### 5.2.3.3 CALIB



**CAUTION:** Calibration parameters must be correct for the instrument to function properly.

The CALIB (CALIBRATION) menu allows the user access to the calibration parameters for the instrument. Access to the heat source and readout calibration parameters is protected by a password. Calibration parameters are programmed at the factory when the instrument is calibrated. These parameters may be adjusted to improve the accuracy of the instrument by qualified personnel.



**CAUTION:** DO NOT change the values of the control parameters from the factory set values unless you are recalibrating the instrument. The correct setting of these parameters is important to the safe and proper operation of the block.

The parameters in the CALIB menu are set at the factory and must not be altered unless recalibrating the instrument. Recalibration of the instrument should be performed by trained, knowledgeable personnel. The correct values are important to the accuracy and proper and safe operation of the block. Access to these parameters is protected by a password. In the event that the calibration parameters need to be reentered into the instrument, these constants and their settings are listed in the Report of Calibration shipped with the instrument.

#### 5.2.3.3.1 CAL POINTS

The CAL POINTS (CALIBRATION POINTS SETUP) menu contains the heat source calibration constants, TEMP CALPT 1, TEMP CALPT 2, and TEMP CALPT 3. Use the arrow keys to enter the set-point for each calibration point and press “Enter” to accept the entry. The calibration points should be selected applicable to model with a low, mid-range, and high set-point.

##### 5.2.3.3.1.1 TEMP 1

The TEMP 1 parameter is the offset in °C for the heat source accuracy at the 1st calibration point.

##### 5.2.3.3.1.2 TEMP 2

The TEMP 2 parameter is the offset in °C for the heat source accuracy at the 2nd calibration point.

##### 5.2.3.3.1.3 TEMP 3

The TEMP 3 parameter is the offset in °C for the heat source accuracy at the 3rd calibration point.

### *5.2.3.3.1.4 GRAD 1*

The GRAD 1 parameter is ratio for the top zone heater control for the axial gradient calibration at the 1st calibration point.

### *5.2.3.3.1.5 GRAD 2*

The GRAD 2 parameter is ratio for the top zone heater control for the axial gradient calibration at the 2nd calibration point.

### *5.2.3.3.1.6 GRAD 3*

The GRAD 3 parameter is ratio for the top zone heater control for the axial gradient calibration at the 3rd calibration point.

### *5.2.3.3.1.7 GRAD 4 (FB660 only)*

The GRAD 4 parameter is a ratio for the top zone heater control for the axial gradient calibration at the fourth calibration point.

### *5.2.3.3.1.8 GRAD 5 (FB660 only)*

The GRAD 5 parameter is a ratio for the top zone heater control for the axial gradient calibration at the fifth calibration point.

### *5.2.3.3.1.9 CALDATE*

The CALDATE parameter is the calibration date for the heat source. Use the arrow keys to enter the calibration date in the format selected in DATE FORMAT.

## **5.2.3.3.2 CONTRL**

The CONTRL (CONTROL SETUP) menu is used to access the controller parameters.

## **5.2.3.3.3 TEMP PB**

The TEMP PB parameter is the main zone proportional band and the gain in °C that the instrument's proportional-integral-derivative (PID) controller uses for main zone control.

### *5.2.3.3.3.1 TEMP INT*

The TEMP INT parameter is the main zone integral, which is the integration time in seconds that the instrument's PID controller uses for main zone control.

### *5.2.3.3.3.2 TEMP DER*

The TEMP DER parameter is the main zone derivative, which is the derivative time in seconds that the instrument's PID controller uses for main zone control.

#### **5.2.3.3.4 CAL REF (-R model only)**

The CAL REF (REFERENCE INPUT CALIBRATION) menu is used to access the reference PRT calibration parameters. Use these parameters to adjust the measurement at 0 and 100Ω.

##### *5.2.3.3.4.1 REF1C0*

The REF1C0 parameter is the first calibration point for the reference resistance.

##### *5.2.3.3.4.2 REF1C100*

The REF1C100 parameter is the second calibration point for the reference resistance.

##### *5.2.3.3.4.3 INPUT CAL DATE*

The INPUT CAL DATE parameter is the calibration date for the readout. Use the arrow keys to enter the calibration date in the format selected in DATE FORMAT.

#### **5.2.3.4 SYSTEM INFO (view only)**

The SYSTEM INFO (SYSTEM INFORMATION) menu displays manufacturer information regarding the instrument.

##### **5.2.3.4.1 MODEL**

The MODEL parameter displays the model number of the instrument.

##### **5.2.3.4.2 SERIAL**

The SERIAL (SERIAL NUMBER) parameter displays the serial number of the instrument.

##### **5.2.3.4.3 FW VER**

The FW VER (FIRMWARE VERSION) parameter displays the firmware version used in the instrument.

##### **5.2.3.4.4 CAL DATE**

The CAL DATE (CALIBRATION DATE) parameter displays the calibration date of the heat source.

##### **5.2.3.4.5 INPUT CAL DATE (-R model only)**

The INPUT CAL DATE (-R CALIBRATION DATE) parameter displays the calibration date for the readout or the -R module.

**5.2.4 INPUT SETUP (-R model only)**

The INPUT SETUP menu allows all the parameters related to the -R module or readout function of the instrument to be accessed. The parameters found in this menu affect the performance, accuracy and display type of the reference PRTs.

**5.2.4.1 REF INPUT**

The REF INPUT (REFERENCE INPUT) menu contains the parameters for the reference input to the readout module of the instrument. The Reference Input is only compatible with PRTs with ITS-90, Callendar Van-Dusen, or IEC-60751 coefficients. Additionally, the Reference Input will read straight resistance.

The probe serial number and coefficients can be found on the calibration certificate that was shipped with the probe. If the probe requires calibration, contact an Authorized Service Center to inquire about calibration services.

**5.2.4.1.1 PROG PROBE**

The PROG PROBE (REFERENCE PROBE SETUP) menu is used to setup the reference probe parameters.

*5.2.4.1.1.1 SERIAL*

The SERIAL (SERIAL NUMBER) parameter allows the user to enter ten digit alpha numeric serial number for the reference probe. Character range = {0-9, A-Z, '-', '<Blank>}. Minimum required is 1 character.

When a blank space is entered, any characters after the blank are dropped. For example, change S/N 1234-5678 to S/N TEST1. Enter TEST1<Blank Space>678. The serial number will drop the last three characters and enter the S/N TEST1.

*5.2.4.1.1.2 CAL DATE*

The CAL DATE parameter is used to enter the calibration date for the reference probe. Use the arrow keys to enter the calibration date in the format selected in DATE FORMAT.

*5.2.4.1.1.3 PROBE TYPE*

The PROBE TYPE parameter is used to choose which probe conversion type to be setup. Use the left and right arrow keys to select the conversion type and press "Enter" to accept selection.

*5.2.4.1.1.3.1 TYPE (ITS-90)*

The TYPE parameter can be ITS-90, Callendar Van-Dusen (CVD), IEC-60751, or Resistance. The ITS-90 option is for PRTs calibrated and characterized using the International Temperature Scale of 1990 (ITS-90) equations. Subranges 4, and 7 through 11 are supported. The parameters that appear when ITS-90 is selected are "Serial" (Serial Number), "Cal Date", "RTPW", "COEF A", "COEF B", "COEF C", "COEF A4",

and “COEF B4”. These should be set with the corresponding values that appear on the calibration certificate of the PRT. The parameter “RTPW” takes the triple point of water resistance, often labeled “R0.01” or “R(273.16K)” on the certificate. Parameters “COEF A”, “COEF B”, “COEF C” take the  $a_n$ ,  $b_n$  and  $c_n$  coefficients where  $n$  is a number from 7 to 11. Parameters “COEF A4” and “COEF B4” take the  $a_4$  and  $b_4$  coefficients on the certificate. Any ITS-90 parameter of the instrument that does not have a corresponding coefficient on the PRT’s certificate must be set to 0.

The following table (Table ) shows which parameter to set for each of the coefficients that may appear on the certificate. The example that follows demonstrates how to set the ITS-90 parameters for certain cases.

**Table 4** Matching Certificate Values to ITS-90 Coefficients

ITS-90 Coefficient	Certificate Value
COEF A	a7, a8, a9, a10, or a11
COEF B	b7, b8, b9, or 0
COEF C	c7 or 0
COEF A4	a4
COEF B4	b4



**NOTE:** If the certificate has two sets of coefficients, one set for “zero-power” calibration and one set for 1 mA calibration, use the coefficients for the 1 mA calibration.

Example 1:

A PRT was calibrated to ITS-90 and its calibration certificate states values for coefficients Rtpw, a4, b4, a8, and b8. Set the instrument’s parameters with values from the certificate as follows.

**Table 5** Setting Coefficients Rtpw, a8, b8, and b4

Coefficient	Certificate Value
RTPW	Rtpw
COEF A	a8
COEF B	b8
COEF C	0
COEF A4	a4
COEF B4	b4

#### 5.2.4.1.1.3.1.1 PROG PROBE

The PROG PROBE parameter is used to tell the instrument to program a Smart Lemo with the appropriate probe coefficients. Use the arrow keys to select “Yes” or “No”. If “Yes” is selected, the Smart Lemo will be programmed with the appropriate coefficients for the selected conversion type. For ITS-90 and CVD, the coefficient values need to be entered before programming the Smart Lemo. For IEC-60751 and Resistance, no values are required to program the Smart Lemo.

## 5.2.4.1.1.3.2 TYPE (CVD)

The CVD (Callendar-Van Dusen) conversion is for RTD probes that use the Callendar-Van Dusen equation:

$$r(t[{}^{\circ}\text{C}]) = \begin{cases} R_0 \left\{ 1 + \alpha \left[ t - \delta \frac{t}{100} \left( \frac{t}{100} - 1 \right) \right] \right\} & t \geq 0 \\ R_0 \left\{ 1 + \alpha \left[ t - \delta \frac{t}{100} \left( \frac{t}{100} - 1 \right) \right] - \beta \left( \frac{t}{100} - 1 \right) \left( \frac{t}{100} \right)^3 \right\} & t < 0 \end{cases}$$

The parameters that appear when CVD is selected are “Serial” (Serial Number), “Cal Date”, “R0”, “ALPHA”, “DELTA” and “BETA”, which can be set by the user. For IEC-751, DIN-43760 or ASTM E1137 sensors, the coefficients for R0, ALPHA, DELTA, and BETA are 100.0, 0.00385055, 1.4998, and 0.1086 respectively.

Some probes may be provided with A, B, and C coefficients for the Callendar-Van Dusen equation in the following form:

$$r(t[{}^{\circ}\text{C}]) = \begin{cases} R_0 (1 + At + B^2) & t \geq 0 \\ R_0 [1 + At + Bt^2 + C(t-100)t^3] & t < 0 \end{cases}$$

The A, B, and C coefficients can be converted to Alpha, Beta and Delta coefficients using the following equation:

$$\alpha = A + 100B \quad \delta = -\frac{100}{\frac{A}{100B} + 1} \quad \beta = -\frac{10^8 C}{A + 100B}$$

## 5.2.4.1.1.3.2.1 PROG PROBE

The PROG PROBE parameter is used to tell the instrument to program a Smart Lemo with the appropriate probe coefficients. Use the arrow keys to select “Yes” or “No”. If “Yes” is selected, the Smart Lemo will be programmed with the appropriate coefficients for the selected conversion type. For ITS-90 and CVD the coefficient values need to be entered before programming the Smart Lemo. For IEC-60751 and Resistance, no values are required to program the Smart Lemo.

## 5.2.4.1.1.3.3 TYPE (IEC-60751)

The IEC-60751 conversion is for RTD probes that use the International Electrotechnical Commission (IEC) Standard Publication 751.

**5.2.4.1.1.3.3.1** PROG PROBE

The PROG PROBE parameter is used to tell the instrument to program a Smart Lemo with the appropriate probe coefficients. Use the arrow keys to select “Yes” or “No”. If “Yes” is selected, the Smart Lemo will be programmed with the appropriate coefficients for the selected conversion type. For ITS-90 and CVD the coefficient values need to be entered before programming the Smart Lemo. For IEC-60751 and Resistance, no values are required to program the Smart Lemo.

**5.2.4.1.1.3.4** TYPE (RESISTANCE)

The RESISTANCE option displays the resistance, in ohms, of the selected reference probe. This temporarily overrides the temperature conversion. The temperature conversion can be restored without losing coefficients.

**5.2.4.1.2** TEST CALC

The TEST CALC (TEST REFERENCE CALCULATION) allows the technician to test the output of a specific conversion algorithm. Simply select the conversion type and enter a value for the requested parameter. Press ENTER, the algorithm computes the answer, and it is displayed immediately in the parentheses at the bottom of the screen, TEMPERATURE: XX.XXX.



## **6 Digital communication interface**

The Field Temperature Block is capable of communicating with and being controlled by other equipment through the RS-232 digital interface.

With a digital interface the instrument may be connected to a computer or other equipment. This allows the user to input the set-point temperature, monitor the temperature, communicate with the readout to obtain measurement data, control operating conditions and access any of the other controller functions, all using remote communications equipment. The RS-232 serial interface allows serial digital communications over fairly long distances. With the serial interface, the user may access any of the functions, parameters and settings discussed in this section.

### **6.1 Wiring**

The serial communications cable attaches to the instrument through the DB-9 connector at the front of the instrument. Figure 14 on next page, shows the pin-out of this connector and suggested cable wiring. To eliminate noise, the serial cable should be shielded with low resistance between the connector (DB9) and the shield.



#### **6.1.1 Setup**

Before operation the serial interface must first be set up by programming the BAUD rate and other configuration parameters. These parameters are programmed within the communications menu. The serial interface parameters can be accessed from the main menu by MENU|SYSTEM MENU|SYSTEM SETUP|COMM SETUP|. For more information on the serial interface parameters, see Section 5.2.3.1.2COMM SETUP on page 33.

#### **6.1.2 Serial Operation**

The serial communications uses 8 data bits, one stop bit, and no parity. The set-point and other commands may be sent via the serial interface to set the temperature set-point and view or program the various parameters. The interface commands are discussed in the “Digital Interface” section.

## RS-232 Cable Wiring for IBM PC and Compatibles



*Figure 14 RS-232 wiring*

## 6.2 Command Syntax

Field Temperature Blocks accept commands for setting parameters, executing functions or responding with requested data. These commands are in the form of strings of ASCII-encoded characters. As far as possible, the Field Temperature Block command syntax conforms to SCPI-1994. One notable exception is that compound commands are not allowed as explained below.

Commands consist of a command header and, if necessary, parameter data. All commands must be terminated with either a carriage return (ASCII 0D hex or 13 decimal) or new line character (ASCII 0A hex or 10 decimal).

Command headers consist of one or more mnemonics separated by colons (:). Mnemonics may use letter characters, the underscore character (  ), and possibly numeric digits as well. Commands are not case sensitive. Mnemonics often have alternate

forms. Most mnemonics have a long form that is more readable and a short form consisting of three or four characters that is more efficient.

A mnemonic may end with a numeric suffix that specifies one of a set of independent function blocks such as input channel data paths. If a numeric suffix is omitted when a particular block must be specified, an error is generated (“Header suffix out of range”).

Query commands are commands that request data in response. Query commands have a question mark (?) immediately following the command header. Responses to query commands are generated immediately and placed in the output buffer. Responses are then transmitted automatically over the RS-232 port. Responses are lost if not read before the next command is received.

Some commands require parameter data to specify values for one or more parameters. The command header is separated from the parameter data by a space (ASCII 20 hex or 32 decimal). Multiple parameters are separated by a comma(,).

Field Temperature Blocks do not allow compound commands (multiple commands per line separated with semicolons). All commands are sequential. The execution of each command is completed before subsequent commands are processed.

### 6.3 Commands by Function or Group

In this section, the commands are arranged into the following groups:

**Calibration Commands** – commands for Field Temperature Block calibration parameters.

**Main Screen Commands** – commands for parameters displayed on the main screen.

**Program Commands** – commands for program setup and status.

**Reference Commands** – commands for accessing reference thermometer parameters.

**Setup Commands** – commands for setting up communication, display, password, measure, and operation parameters.

**System Commands** – commands to report and change the status of the instrument.

**Temperature Commands** – commands for control temperature and cutout functions.

**Table 6** *Commands by Function or Group*

	<b>SCREEN PARAMETER</b>	<b>Command</b>	<b>Password Protection Group</b>	<b>Read/Write</b>
<b>Calibration - Controller</b>	TEMP PB	SOUR:LCON:PBAN	Unconditional	R/W
	TEMP INT	SOUR:LCON:INT	Unconditional	R/W
	TEMP DER	SOUR:LCON:DER	Unconditional	R/W
	CALDATE	CAL:DATE:UNIT	Unconditional	R/W

## FBXXX Field Temperature Block

Commands by Function or Group

	SCREEN PARAMETER	Command	Password Protection Group	Read/Write
<b>Calibration – Heat Source</b>	TEMP 1	SOUR:SENS:CAL:PAR1	Unconditional	R/W
	TEMP 2	SOUR:SENS:CAL:PAR2	Unconditional	R/W
	TEMP 3	SOUR:SENS:CAL:PAR3	Unconditional	R/W
	GRAD 1	SOUR:SENS:CAL:GRAD1	Unconditional	R/W
	GRAD 2	SOUR:SENS:CAL:GRAD2	Unconditional	R/W
	GRAD 3	SOUR:SENS:CAL:GRAD3	Unconditional	R/W
	GRAD 4	SOUR:SENS:CAL:GRAD4	Unconditional	R/W
	GRAD 5	SOUR:SENS:CAL:GRAD5	Unconditional	R/W
	TEMP 1	SOUR:SENS:CAL:TEMP1	N/A	R
	TEMP 2	SOUR:SENS:CAL:TEMP2	N/A	R
TEMP 3	SOUR:SENS:CAL:TEMP3	N/A	R	
<b>Calibration – Reference (-R model only)</b>	REF1C0	SENS1:CAL:PAR1	Unconditional	R/W
	REF1C100	SENS1:CAL:PAR2	Unconditional	R/W
	INPUT CAL DATE	CAL:DATE:MOD	Unconditional	R/W
<b>Main Screen</b>	(none)	SOUR:SENS:DATA	N/A	R
	SETPT	SOUR:SPO	N/A	R/W
	STAB	SOUR:STAB:DAT	N/A	R
	STAB graph	SOUR:STAB:TEST	N/A	R
	HEAT %	OUTP1:DATA	N/A	R
	(none)	OUTP2:DATA	N/A	R
	ENABLE	OUTP1:STAT	N/A	R/W
<b>(-R model only)</b>	REF	CALC1:DATA	N/A	R
<b>(-R model only)</b>	REF TEMP	READ, MEAS, FETC	N/A	R
<b>Program – Run</b>	TEST STATUS	PROG:STAT	N/A	R/W
<b>Program - List</b>	(none)	PROG:CAT	N/A	R
<b>Program - Select</b>	(none)	PROG:TYP	N/A	R/W
<b>Program - Setup</b>	TEST ID	PROG:IDEN	N/A	R/W
	(none)	PROG:MEM:COUN	N/A	R
<b>Erase Tests</b>	ERASE TESTS	PROG:MEM:CLEA	Unconditional	W
<b>Ramp &amp; Soak</b>	RAMP/SOAK SETUP	PROG:SEQ:CAT	N/A	R
	SETPOINT n	PROG:SEQ:PAR SPO <sub>n</sub>	Conditional	R/W
	SOAK TIME	PROG:SEQ:PAR DWEL	Conditional	R/W
	SETPOINTS	PROG:SEQ:PAR POIN	Conditional	R/W
	NO CYCLES	PROG:SEQ:PAR CYCL	Conditional	R/W
	PASS TOLERANCE	PROG:SEQ:PAR PTOL	Conditional	R/W
	DIRECTION	PROG:SEQ:PAR DIR	Conditional	R/W
	SETPOINT 1	SOUR:LIST:SPO1	N/A	R/W
	SETPOINT 2	SOUR:LIST:SPO2	N/A	R/W
	SETPOINT 3	SOUR:LIST:SPO3	N/A	R/W
	SETPOINT 4	SOUR:LIST:SPO4	N/A	R/W
	SETPOINT 5	SOUR:LIST:SPO5	N/A	R/W
	SETPOINT 6	SOUR:LIST:SPO6	N/A	R/W
SETPOINT 7	SOUR:LIST:SPO7	N/A	R/W	
SETPOINT 8	SOUR:LIST:SPO8	N/A	R/W	
<b>Test – Results (-R model only)</b>	PRINT TEST	PROG:MEM:PRINT	N/A	W
	ERASE TESTS	PROG:MEM:CLEA	Unconditional	W

	<b>SCREEN PARAMETER</b>	<b>Command</b>	<b>Password Protection Group</b>	<b>Read/Write</b>
<b>Reference - List (-R model only)</b>	PROBE TYPE	CALC1:CONV:CAT	N/A	R
<b>Characterization Parameters - Active List (-R model only)</b>	(none)	CALC1:CONV:PAR:CAT	N/A	R
	CAL DATE	CALC1:CONV:DATE	Conditional	R/W
	PROGRAM	CALC1:CONV:PROG	Unconditional	W
<b>Reference – Setup (-R model only)</b>	PROBE TYPE: ITS-90	CALC1:CONV:NAME ITS-90	Conditional	R/W
<b>Reference – Setup (-R model only)</b>	PROBE TYPE: CVD	CALC1:CONV:NAME CVD	Conditional	R/W
<b>Reference – Setup (-R model only)</b>	PROBE TYPE: IEC	CALC1:CONV:NAME IEC-751	Conditional	R/W
<b>Reference – Setup (-R model only)</b>	CONV TYPE: RESISTANCE	CALC1:CONV:NAME RES	Conditional	R/W
<b>(-R model only)</b>	SERIAL	CALC1:CONV:SNUM	Conditional	R/W
<b>ITS90 (-R model only)</b>	RTPW	CALC1:CONV:PAR:VAL RTPW	Conditional	R/W
	A	CALC1:CONV:PAR:VAL A7	Conditional	R/W
	B	CALC1:CONV:PAR:VAL B7	Conditional	R/W
	C	CALC1:CONV:PAR:VAL C7	Conditional	R/W
	A4	CALC1:CONV:PAR:VAL A4	Conditional	R/W
	B4	CALC1:CONV:PAR:VAL B4	Conditional	R/W
<b>CVD (-R model only)</b>	R0	CALC1:CONV:PAR:VAL R0	Conditional	R/W
	ALPHA	CALC1:CONV:PAR:VAL AL	Conditional	R/W
	DELTA	CALC1:CONV:PAR:VAL DE	Conditional	R/W
	BETA	CALC1:CONV:PAR:VAL BE	Conditional	R/W
	RESISTANCE	SENS1:DATA	N/A	R
<b>Reference – Test Algorithm (-R model only)</b>	TEST CALC	CALC1:CONV:TEST	N/A	R
<b>Setup - Communication</b>	BAUD RATE	SYST:COMM:SER:BAUD	N/A	R/W
	LINEFEED	SYST:COMM:SER:LIN	N/A	R/W
<b>Setup - Display</b>	LANGUAGE	SYST:LANG	N/A	R/W
	DECIMAL	SYST:DEC:FORM	N/A	R/W
	KEY AUDIO	SYST:BEEP:KEYB	N/A	R/W
<b>Setup - Password</b>	PASSWORD (Disable)	SYST:PASS:CDIS	Unconditional	W
	PASSWORD (Enable)	SYST:PASS:CEN	Unconditional	W
<b>Status</b>	(none)	SYST:PASS:CEN:STAT	N/A	R
	USER PASSWORD	SYST:PASS:NEW	Unconditional	W
	PROTECTION	SYST:PASS:PROT	N/A	R/W
<b>Setup – Date/Time</b>	DATE	SYST:DATE	Unconditional	R/W
	TIME	SYST:TIME	Unconditional	R/W
<b>System - Setup</b>	°C/°F key	UNIT:TEMP	N/A	R/W
<b>Heat Enable</b>	(none)	OUTP:STAT	N/A	R/W
	(none)	SYST:KLOC	Conditional	R/W
	(none)	SYST:CONF:MOD	N/A	R

## FBXXX Field Temperature Block

### Serial Commands - Alphabetic Listing

	SCREEN PARAMETER	Command	Password Protection Group	Read/Write
System - Information	(none)	SYST:ERR	N/A	R
	(all)	*IDN	N/A	R
	(none)	*CLS	N/A	W
	(none)	*OPT	N/A	R
	FW VER	SYST:COD:VERS	N/A	R
	(none)	SYST:BEEP:IMM	N/A	W
Temperature – Cutout	HARD CUTOUT	SOUR:PROT:HCUT	N/A	R
	SOFT CUTOUT	SOUR:PROT:SCUT:LEV	Conditional	R/W
Reset	(none)	SOUR:PROT:CLE	N/A	W
Trip State	(none)	SOUR:PROT:TRIP	N/A	R
Temperature - Setup	SCAN RATE	SOUR:RATE	N/A	R/W
	STABLE LIMIT	SOUR:STAB:LIM	N/A	R/W
	STABLE ALARM	SOUR:STAB:BEEP	N/A	R/W

## 6.4 Serial Commands - Alphabetic Listing

Each command description provides the structure (long and short format), a description of the command purpose, a command example, an example of what the command returns (as applicable to query commands), and notes specific to the command. The following apply to each group of commands:

- Numeric data, specified by the mnemonic, <num>, uses ASCII characters to represent numbers. Numbers may contain a plus or minus ('+' or '-') sign, decimal point ('.'), and exponent ('E' or 'e') with its sign. If a fractional component is received when only an integer is required, the number is rounded to the nearest integer without any resulting error message. The mnemonics DEF, MIN, and MAX are often acceptable for the default, minimum, and maximum value respectively. Unit suffixes, such as V or OHM, can be appended to numeric parameters and are accepted without error but ignored.
- Unrecognized commands or commands with incorrect syntax or invalid parameters generate error messages in the error queue.
- Upper case letters designate syntax that is required when issuing the command. Lower case letters are optional and may be omitted.
- <> indicates a required parameter.
- [ ] indicates optional parameters.
- ( ) indicates a group of parameters that must be used together.
- For query commands, specifying the MIN, MAX, or DEF parameter causes the instrument to respond with the minimum, maximum, or default setting respectively.
- For set commands, specifying the MIN, MAX, or DEF parameters causes the instrument to use the minimum, maximum, or default setting respectively.
- '?' indicates alternate parameter values.
- <n> indicates a number is required.
- <num> indicates numeric value is required.
- <prog> indicates a program number (SEQ<n> or SWIT<n>) is required.

- <bool> indicates a Boolean value (0 or 1) is required. The mnemonics OFF and ON are also accepted for 0 and 1, respectively.
- <conv> indicates a conversion mnemonic is required.
- <param> indicates a parameter name is required.
- <seri> indicates a serial number is required.
- <res> indicates a resistance value is required.
- <volt> indicates a voltage value is required.
- <unit> indicates a temperature unit is required.
- <temp> indicates a temperature °C/F is required.
- <pass> indicates a password is required.
- <port> indicates a port number is required.
- <label> indicates an eight character label is required.
- <year> indicates a four digit number is required.
- <month> indicates a one or two digit number is required.
- <day> indicates a one or two digit number is required.
- <hour> indicates a one or two digit number is required.
- <minute> indicates a one or two digit number is required.
- <second> indicates a one or two digit number is required.
- <baud> indicates a valid baud number is required.

**\*CLS**

Clear the status registers

Example: \*CLS

This command has no response.

Clears all status registers (events, operations etc).

**\*IDN?**

Read the product information (Manufacturer, Model Number, Serial Number, and Firmware Version)

Example: \*IDN?

Response: BEAMEX,FB150,A79002,1.00

**\*OPT?**

Read the product configuration, reference hardware enabled (1) or not (0) (see SYST:CONF:MOD) plus Russian configuration set (2) or not (0)

Example: \*OPT?

Response: 1

This command is a read only command and returns the state of the reference functionality (0, 1).

### **CAL:DATE:MOD[?] [<year>,<month>,<day>] (-R model only)**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Read or set the calibration date for the -R Module (INPUT CALibration DATE) where the entered values are all numeric and “yyyy” is a four digit year (2000-2135), “mm” is a two digit month (1-12), and “dd” is a two digit day (1-31)

Read Example: CAL:DATE:MOD?

Response: 2007,05,24

Set Example: CAL:DATE:MOD 2007,12, 30

This command reads or sets the calibration date for the -R module including all accompanying sensors.

### **CAL:DATE:UNIT[?] [<year>,<month>,<day>]**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Read or set the calibration date for the Main Unit where the entered values are all numeric and “yyyy” is a four digit year (2000-2135); default 2007, “mm” is a two digit month (1-12), and “dd” is a two digit day (1-31)

Read Example: CAL:DAT:UNIT?

Response: 2007,05,24

Set Example: CAL:DAT:CAL 2006,12, 30

This command reads or sets the calibration date for the Main Unit. Calibration is for the heat source portion of the instrument.

### **CALC1:CONV:CAT? (-R model only)**

Read the list of reference probe characterization methods, “CVD, I90, IEC, RES”

Example: CALC1:CONV:CAT?

Response: “CVD”, ”I90”, ”IEC”, ”RES”

Provides the list of PRT/RTD characterization methods available.

**CALC1:CONV:DATE[?] [<yyyy,mm,dd>] (-R model only)**



*NOTE: This command is conditionally protected, which requires a password to set it.*

Read or set the Smart Lemo probe calibration date in yyyy,mm,dd format

Year Range = {2000 – 2135}; Default: 2007

Month Range = {1 – 12}; Default: 1

Day Range = {1 – 31}; Default: 1

Read Example: CALC1:CONV:DATE?

Response: 2007,10,09

Set Example: CALC1:CONV:DATE 2007,09,06

This command reads or sets the calibration date for the Smart Lemo probe.

**CALC1:CONV:NAME[?][n] (-R model only)**



*NOTE: This command is conditionally protected, which requires a password to set it.*

Read or set the reference probe characterization method where “n” is an alpha numeric value; CVD, I90, IEC, and RES. Range={ITS90, CVD, IEC, RES} or 0-3, Default:ITS90

Read Example: CALC1:CONV:NAME?

Response: CVD

Set Example: CALC1:CONV:NAME I90

Reads or sets the reference probe characterization method from a predefined set of options.

**CALC1:CONV:PAR:CAT? (-R model only)**

Read the list of active reference probe characterization parameter names

Example: CALC1:CONV:PAR:CAT?

Response: “RTPW”,”A”,”B”,”C”,”A4”,”B4”

This command is a read only command, which returns the active parameters for the current reference probe type.

**CALC1:CONV:PAR:VAL[?] par[,<n>] (-R model only)**

**NOTE:** This command is conditionally protected, which requires a password to set it.

Read or set a reference probe characterization parameter. Where “par” is a parameter identified as follows: ITS90: RTPW, A7, B7, C7, A4, B4; or CVD: AL, DE or BE. “n” may be some real number or an exponential value such as -1.234567e-5 for ITS-90

ITS-90 Ranges: {RTPW, A7, B7, A4, B4} or 0 - 5

RTPW = 1.0 to 200 ohms

Coefficients =  $\pm 0.010$

Defaults: RTPW = 100

All ITS-90 coefficients = 0.00000

CVD Ranges/Defaults: {R0, AL, DE, BE} or 0 - 3

R0 = 1.0 to 200.00 ohms

R0 Default = 100.00

AL Range = 0.1 to 0.9

AL Default = 0.00385055

BE Range = 0.0 to 1.0

BE Default = 0.10863

DE Range = 0.0 to 2.0

DE Default = 1.499786

Read Example: CALC1:CONV:PAR:VAL? RTPW

Response: 100.4545

Set Example: CALC:CONV:PAR:VAL A7, 0.00385075

This command returns a reference probe characterization parameter as desired by the user.

**CALC1:CONV:PROG (-R model only)**

**NOTE:** This command is unconditionally protected, which requires a password to set it.

Program the Smart Lemo probe with the current probe settings

Example: CALC1:CONV:PROG

**CALC1:CONV:SNUM[?] <ser\_num> (-R model only)**

**NOTE:** This command is conditionally protected, which requires a password to set it.

Read or set the reference probe serial number, where “ser\_num” character range equals {0-9, A-Z, ‘-‘}, up to 10 characters in length with a minimum of 1 character length. Default: “0”

When a blank space is entered, any characters after the blank are dropped. For example, change S/N 1234-5678 to S/N TEST1. Enter TEST1<Blank Space>678. The serial number will drop the last three characters and enter the S/N TEST1.

Read Example: CALC1:CONV:SNUM?

Response: 1234

Set Example: CALC1:CONV:SNUM 1560-D

This command allows the user to read or enter a reference probe serial number.

**CALC1:CONV:TEST[?] <n>]**

Test the conversion algorithm from resistance (ohms) to temperature (°C or °F). “n” is the value to be converted (ohms); entry for “n” is required for converted output. Range = {0-500}; Default = 100

Read Example: CALC1:CONV:TEST? 100.000

Response: 0.0100

This is a read only command and tests conversion algorithm from resistance to temperature.

**CAL1:DATA? (-R model only)**

Reads the reference sensor Temperature. The returned value will be in degrees °C (°F) if a temperature value is returned. The value may be resistance depending on the conversion selection

Example: CALC1:DAT?

Response: 325

The command returns an instantaneous reading of the reference sensor Temperature.

**OUTP:STAT[?] [0|1]**

Read or set the Main Heat output enable, off [0] or on [1]

Read Example: OUTP:STAT?

Response: 0

Set Example: OUTP:STAT 1

This command reads or sets the active heating or cooling output status. A “0” is returned if the output status is off, and a “1” is returned if the output status is on

### **OUTP1:DATA?**

Read the main heat output percent

Example: OUTP1:DATA?

Response: 18.0

This command returns the current main zone heater duty cycle

### **OUTP2:DATA?**

Read the gradient heat output percent

Example: OUTP2:DATA?

Response: 57.0

This command returns the current top zone heater percent power.

### **PROG:CAT?**

A catalog list of all define programs: Ramp & Soak = SEQ

Example: PROG:CAT?

Response: “SEQ”

### **PROG:IDEN[?] [n]**

Read or set the program identifier. Character range = {0 – 9, A – Z, ‘-’}, up to 12 characters, minimum 1 character: Default: “0”

Read Example: PROG:IDEN?

Set Example: TEST-1

### **PROG:MEM:CLE (-R Model only)**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Erase all test reports stored in NVMemory

Example: PROG:MEM:CLE

### **PROG:MEM:COUN? (-R Model only)**

Read the test report count.

Example: PROG:MEM:COUN? 6

Provide the count for the number of test reports currently stored in memory.

**PROG:MEM:PRIN [n] [ALL] (-R Model only)**

Prints one or ALL test reports. Where “n” indicates the test report to be printed and 1 is the earliest test.

Example: PROG:MEM:PRINT 1

**PROG:SEQ:CAT?**

Read a list of program parameters for Ramp & Soak tests

Example: PROG:SEQ:CAT?

Response: “SPOn”, ”DWELL”, ”DIR”, ”POIN”, ”CYCL”, ”PTOL”

This command provides a list of the parameters for the Ramp and Soak test.

**PROG:SEQ:PAR? par[,<n>]**

Read or set a program parameter for Ramp & Soak tests. Range = {SPOn, DWELL, DIR, POIN, CYCL, PTOL}.

*Table 7 PROG:SEQ:PAR parameters*

Parameter	Min	Max	Default
SPO[n]*	1	8	1
DWEL	1	100	15
POIN	1	8	8
CYCL	1	999	1
PTOL	0.01	99.9	1.00
DIR	0 (up)	1 (U/D)	0

\*Read Only, must be <= # of setpoints (POIN)

Read Example: PROG:SEQ:PAR? dwell

Response: 25

Set Example: PROG:SEQ:PAR cycle,8

Reads or sets a specified parameter in the Ramp & Soak test.

**PROG:STAT[?] [0|1]**

Read or set the execution state for the selected program. (Off=0, Run=1) Default = 0

Read Example: PROG:STAT?

Response: 0

Set Example: PROG:STAT 1

If the selected program is not running then a value of 0 is returned otherwise a 1 is returned.

**PROG:TYPE[?] [ <prog>]**

Read or select a program to run where “prog” is a name, SEQ. Default = SEQ

Read Example: PROG:TYPE?

Response: SEQ

Set Example: PROG:TYPE SEQ

Reads or selects the current program setting, Ramp & Soak = SEQ.

**READ?, MEAS? or FETC? (-R model only)**

Read the Reference sensor temperature, °C or °F

Example: READ?

Response: 264.262

If the external reference probe is enabled, the reference temperature is returned otherwise 0.0 is returned.

**SENS1:CAL:PAR<n>[?][cal] (-R model only)**

*NOTE: This command is unconditionally protected, which requires a password to set it.*

Read or set a reference input calibration parameter where “n” is a value of 1 or 2 corresponding to the calibration parameters REF1C0 and REF1C100 respectively. “cal” is a real number used as the calibration offset for the respective parameter

REF1C0 Range = {-1.0 to 1.0}

REF1C100 Range = {-2.0 to 2.0}

Defaults (all): 0.0000

Read Example: SENS:CAL:PAR1?

Response: 0.2

Set Example: SENS1:CAL:PAR2 0.092

Reference thermometer input commands to verify or set REF1C0 (PAR1) or REF1C100 (PAR2) calibration parameters.

**SENS1:DATA? (-R model only)**

Read the reference input resistance

Example: SENS1:DATA?

Response: 199.9366

This command returns the resistance in ohms of the reference probe.

### **SOUR:LCON:DER[?] [n]**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Read or set the main control loop derivative time in seconds, Min: 0.0, Max: 99.9

Read Example: SOUR:LCON:DER?

Response: 1.5

Set Example: SOUR:LCON:DER 5

The main zone derivative is the derivative time in seconds that the instrument's PID controller uses for main zone control.

### **SOUR:LCON:INT[?] [n]**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Read or set the main control loop integral time in seconds. Range = {10.0-999.9}

Read Example: SOUR:LCON:INT?

Response: 20.0

Set Example: SOUR:LCON:INT 10

The main zone integral is the integration time in seconds that the instrument's PID controller uses for main zone control.

### **SOUR:LCON:PBAN[?] [n]**



***NOTE:** This command is unconditionally protected and requires a password to set it.*

Read or set the main control loop proportional band, °C. Range = {1.0-99.9}

Read Example: SOUR:LCON:PBAN?

Response: 1.5

Set Example: SOUR:LCON:PBAN 7

The main zone proportional band is the gain in °C that the instrument's proportional-integral-derivative (PID) controller uses for main zone control.

**SOUR:LIST:SPO<i>[?] [n]**

Read or set a main temperature preset set-point

Read example: SOUR:LIST:SPO6?

Response: 25.00

Set Example: SOUR:LIST;SPO6 100.00

This sets the preset set-points found in PROG MENU under RAMP/SOAK.

**SOUR:PROT:HCUT?**

Read the hard cutout temperature set-point in °C or °F

Read Example: SOUR:PROT:HCUT?

Response: 140

Returns the current value of the hard cutout set-point.

**SOUR:PROT:CLEA**

Reset the cutout to enable the system

Example: SOUR:PROT:CLEA

This command has no response.

If the Field Temperature Block exceeds the temperature set in the soft cutout menu or if it exceeds the maximum operating temperature of the instrument, a cutout condition occurs. If this happens, the instrument enters cutout mode and will not actively heat or cool until the user issues this command to clear the cutout or resets the instrument using the Setpt. key to clear the cutout mode and activate the instrument.

**SOUR:PROT:SCUT:LEV[?] [n]**

*NOTE: This command is conditionally protected and requires a password to set it.*

Read or set the soft cutout set-point where “n” is an integer value from 0 to 700

FB150 Range = {−25.00 to 165.00}

FB350 Range = {25.00 to 365.00}

FB660 Range = {25.00 to 670.00}

Read Example: SOUR:PROT:SCUT:LEV?

Response: 125

Set Example: SOUR:PROT:SCUT:LEV 450

Read or set the soft cutout set-point. The soft cutout should be set to protect the temperature limits of the instruments under test.

**SOUR:PROT:TRIP?**

Read the temperature cutout tripped state. Range = {0, 1}; 0 = No Cutout; 1 = Cutout

Example: SOUR:PROT:TRIP?

Response: 0

A value of 0 is returned if the cutout set point has not been reached. Otherwise a value of 1 is returned and the cutout set point has been reached.

**SOUR:RATE[?] [n]**

Read or set the control temperature rate of change (Scan Rate), °C or °F per minute.

Min: 0.10, Max: 500.00; Default: 100.00

Read Example: SOUR:RATE?

Response: 0.531

Set Example: SOUR:RATE 1.26

The response to this command starts out high initially and decreases as the set point is reached.

**SOUR:SENS:CAL:GRAD<x>[?] [n]**

*NOTE: This command is unconditionally protected and requires a password to set it.*

Read or set the axial gradient control parameter, where “x” is a numeric value indicating the parameter. [1] = GRAD1 = GRAD 1, [2] = GRAD2 = GRAD 2, [3] = GRAD3 = GRAD 3, [4] = GRAD4 = GRAD 4, [5] = GRAD5 = GRAD 5. “n” is a real number ranging from -1.0 to 1.0 entered as a ratio of the main heater power

Read Example: SOUR:SENS:CAL:GRAD2?

Response: 0.05

Set Example: SOUR:SENS:CAL:GRAD2 0.08

The top zone heater reacts as a ratio of the mains heater power to control the axial gradient.

**SOUR:SENS:CAL:PAR<x>[?] [n]**

*NOTE: This command is unconditionally protected and requires a password to set it.*

Read or set a control temperature calibration parameter, where “x” is a numeric value indicating the parameter. [1] = PAR1=Temp 1, PAR2=Temp 2, PAR3=Temp 3. “n” is the entered value of the parameter. Range = ±50.00; Defaults: 0.000

## FBXXX Field Temperature Block

Serial Commands - Alphabetic Listing

---

Read Example: SOUR:SENS:CAL:PAR1?

Response: 0.0

Set Example: SOUR:SENS:CAL:PAR2 0.02

This command reads or sets the calibration parameter value for main control.

### **SOUR:SENS:CAL:TEMP<x>?**

Read the required calibration temperature (°C) corresponding to a calibration parameter where “x” is a numeric value indicating the parameter [1] = TEMP1, [2] = TEMP2, AND [3] = TEMP3. Range = {1-3}; Default = 1

Example: SOUR:SENS:CAL:TEMP1?

Response: 40

### **SOUR:SENS:DATA? [TEMP]**

Read the control temperature, °C or °F

Example: SOUR:SENS:DATA? or SOUR:SENS:DATA? TEMP

Response: 30.285°C (current control temp)

The current control temperature is returned if the above or if TEMP is appended to the end of the example.

### **SOUR:SENS:DATA? [RES]**

Read the control sensor resistance

Example: SOUR:SENS:DATA? RES

Response: 111.28

When RES is appended to the end of the example above, the internal sensor resistance is returned.

### **SOUR:SPO[?] [n]**

Set the control set-point, °C or °F, where “n” is a real value with acceptance limits based on the model

Parameter	Min	Max	Default
FB150	-25.00	150.00	25.00
FB350	25.00	350.00	25.00
FB660	25.00	660.00	25.00

Read Example: SOUR:SPO?

Response: 50.000

Set Example: SOUR:SPO 100.00

This command reads or sets the value of the control set point based on the system temperature units.

**SOUR:STAB:BEEP[?] [n]**

Read or set the stability alert (beep) enable where “n” is a value 0 or 1. [0] is disable, [1] is enable beep. Default:1 (Enable Beep)

Read Example: SOUR:STAB:BEEP?

Response: 1

Set Example: SOUR:STAB:BEEP 0

Enable or disable the audible stability alert.

**SOUR:STAB:DAT?**

Read the control temperature stability, °C or °F

Example: SOUR:STAB:DAT?

Response: 0.306

The controller stability is returned.

**SOUR:STAB:LIM[?] [n]**

Read or set the control temperature stability limit, °C or °F where “n” is a positive real value. Range = {0.01 to 9.99 (°C)}; Default: 0.05 (°C)

Read Example: SOUR:STAB:LIM?

Response: 0.05

Set Example: SOUR:STAB:LIM 0.03

Read or set the control stability limit.

**SOUR:STAB:TEST?**

Read the temperature stability test results. Stable = 1; Unstable = 0

Example: SOUR:STAB:TEST?

Response: 0

A value of 0 is returned if the controller is not stable at the current set-point. Otherwise a value of 1 is returned if the controller is stable at the current set-point.

**SYST:BEEP:IMM**

Beep the system beeper

Example: SYST:BEEP:IMM

The system beeper should make an audible sound in response to this command.

**SYST:BEEP:KEYB[?] [n]**

Read or set the keyboard beep function, 0=Off, 1=On. Default: 1

Read Example: SYST:BEEP:KEYB?

Response: 1

Set Example: SYST:BEEP:KEYB 1

Turns the keyboard beep function on or off.

**SYST:CODE:LANG?**

Read the language set option: 1: European; 2: Russian; 3: Asian. The available languages are dependent upon which version of the product is supplied. The version is dependent upon the final destination and configuration.

- European: ENGLISH (default), FRENch, SPANish, ITALian, GERMan
- Russian: RUSSian (default), ENGLISH
- Asian: ENGLISH (default), CHINese, JAPANese

Example: SYST:CODE:LANG?

Response: 3

**SYST:CODE:VERS?**

Read the main code version

Example: SYST:CODE:VERS?

Response: 1.10

Provides the user with the version of the main processor code.

**SYST:COMM:SER:BAUD[?] [<baud>]**

Read or set serial interface baud rate where “baud” is a standard baud rate value. Range baud = {1200, 2400, 4800, 9600, 19200, and 38400}; Default: 9600

Read Example: SYST:COMM:SER:BAUD?

Response: 2400

Set Example: SYST:COMM:SER:BAUD 9600

**SYST:COMM:SER:LIN[?] [n]**

Set serial interface linefeed enable, where “n” is a value 1 or 0. [0] = LF OFF, [1] = LF ON; Default: 1 (OFF)

Read Example: SYST:COMM:SER:LIN?

Response: 0

Set Example: SYST:COMM:SER:LIN 1

This command enables or disables line feed.

### **SYST:CONF:MOD?**

Read the presence of the -R module; [0] if no -R sensor module, [1] if -R sensor card is installed

Example: SYST:CONF:MOD?

Response: 1

If the -R sensor module is installed, the instrument is a -R Model.

### **SYST:DATE[?] [<year>,<month>,<day>] (-R model only)**



***NOTE:** This command is conditionally protected and requires a password to set it.*

Read or set the System Date Setting using numbers separated by commas (yyyy,mm,dd). Default: <Blank>

Read Example: SYST:DATE?

Response: 2007,05,24

Set Example: SYST:DATE 2007,05,24

### **SYST:DEC:FORM[?] [n]**

Read or set the decimal format, where “n” is period [0], comma [1]. Default: 0 (Period)

Read Example: SYST:DEC:FORM?

Response: 0

Set Example: SYST:DEC:FORM 1

### **SYST:ERR?**

Read the most resent error from the error queue

Example: SYST:ERR?

Response: command protected

This command response reports the errors in the error queue.

**SYST:KLOC[?] [n]**

**NOTE:** This command is unconditionally protected and requires a password to set it.

Read or set the keypad lockout; [0] = unlock, and [1] = lock. Default: 0 (Unlock)

Read Example: SYST:KLOCK?

Response: 1

Set Example: SYST:KLOC 1

This command locks or unlocks the system keypad providing control only through the serial interface (RS-232 port) or the keypad.

**SYST:LANG <lang>**

Set the display language. The available languages are dependent upon which version of the product is supplied. The version is dependent upon the final destination and configuration.

European: ENGLISH (default), FRENch, SPANish, ITALian, GERMan

- Russian: RUSSian (default), ENGLISH
- Asian: ENGLis (default), CHINese, JAPANese
- Example: SYST:LANG SPAN

**SYST:LANG:CAT?**

Read the available display languages. The available languages are dependent upon which version of the product is supplied. The version is dependent upon the final destination and configuration.

- European: ENGLISH (default), FRENch, SPANish, ITALian, GERMan
- Russian: RUSSian (default), ENGLISH
- Asian: ENGLISH (default), CHINese, JAPANese

Example European: SYST:LANG:CAT?

Response: "ENGL", "FREN", "SPAN", "ITAL", "GERM"

Example Russian: SYST:LANG:CAT?

Response: "RUSS", "ENGL"

Example Asian: SYST:LANG:CAT?

Response: "ENGL", "JAP", "CHIN"

**SYST:PASS:CDIS**

Disable access to password protected setting commands

Example: SYST:PASS:CDIS

This command has no response.

This command disables the system password protection.

**SYST:PASS:CEN [n]**

Enable access to password protected setting commands, where “n” is a four digit password. Range = {0000 – 9999}; Default: 1234

Example: SYST:PASS:CEN 1234

This command has no response.

This command enables the system password. This password needs to be enabled in order to use the conditionally protected commands. When the power of the instrument is cycled, system password protection is disabled.

**SYST:PASS:CEN:STAT?**

Read the access state of password protected setting commands.

Example: SYST:PASS:CEN:STAT?

Response: 0

This command reports the current status of the system password.

**SYST:PASS:NEW <n>|DEF**



***NOTE:** This command is unconditionally protected, which requires a password to set it.*

Set the password, where “n” is the new four digit password. Range = {0000 – 9999}; Default: 1234

Example: SYST:PASS:NEW 1234

This command has no response.

This command allows the user to set the system password.

**SYST:PASS:PROT[?] [0|1]**

Read or set password protection level., [0] = low, [1] = high

Read Example: SYST:PASS:PROT?

Response: 0

Set Example: SYST:PASS:PROT 1

**SYST:TIME[?] [<hh,mm,ss>] (-R model only)**

*NOTE: This command is conditionally protected and requires a password to set it.*

Read or set the System Time <hh,mm,ss> (24 hr time only)

Range: hh = {0 – 23}

mm = {0 – 59}

ss = {0 – 59}

Default: Current Time – Pietarsaari, Finland

Read Example: SYST:TIME?

Response: 23,51,05

Set Example: SYST:TIME 14,15,05

**UNIT:TEMP[?] [n]**

Read or set the display temperature units, where “n” is a character “C” or “F”. Default: C

Read Example: UNIT:TEMP?

Response: C

Depending on instruments setting, a C (Celsius) or F (Fahrenheit) is returned.

Set Example: UNIT:TEMP F

**6.5 Non-SCPI Process Commands**

This section contains Non-SCPI commands. These are available for users that require Non-SCPI commands for their application. These commands are used differently from the SCPI commands discussed in the previous section, the command protocol and response is different. These commands do not require a question mark (?) for a query, and respond to a query by first outputting the command and colon before the data. These commands are not password protected. The associated SCPI command is referenced where appropriate.

**6.6 Non-SCPI Commands by Function or Group**

	SCREEN PARAMETER	COMMAND	PASSWORD PROTECTION	READ/WRITE
<b>Setup - Communication</b>	DUPLEX	du	None	R
	LINEFEED	lf	None	R/W
	SAMPLE RATE	sa	None	R/W

<b>Temperature Settings</b>	HIGH LIMIT	hl	None	R
	SET POINT	s	None	R/W
	TEMPERATURE	t	None	R
<b>System Information</b>	VERSION	*ver	None	R
<b>System Setup</b>	°C/°F	u	None	R/W

### **\*ver**

Read the Model number and Main code version (Model Number, Firmware version). A question mark (?) is not required to query this command.

Example: \*ver

ver. FB150, 1.00

### **du**

Read or set serial interface echo enable, on (1) or off (0).

The FB150, FB350 and FB660 do not support the Full duplex mode. The response will be the command string and a colon followed by “Half”.

Read Example: du

du: HALF

Set Example: du 1

This command enables or disables the echo.

### **hl**

Read the maximum temperature setting for the unit. This command is query only and responds with the command string and a Colon followed by the maximum temperature and associated units.

Read Example: hl

hl: 660.00 C

### **If [n]**

Read or set the serial interface linefeed enable, where “n” is a value 1 or 0. [0] = LF OFF, [1] = LF ON. The default setting is Off. (Off and on may be used in place of 0 and 1 respectively). If “n” is left blank, the command will be treated as a query. This query responds with the command string and a Colon followed by the LF setting. Refer to SYST:COMM:SER:LIN command.

Read Example: If

If: OFF

Set Example: If on

## **FBXXX Field Temperature Block**

*Non-SCPI Commands by Function or Group*

---

### **s [n]**

Read or Set the temperature control set-point in °C or °F (based on current system units). Where “n” is a real value with acceptance limits based on the model. If “n” is left blank, the command will be treated as a query. This query responds with the command string “set:” followed by the temperature setting and associated units. Refer to SOUR:SPO command.

Read Example: s

set: 100.00 C

Set Example: s 250

### **sa [n]**

Read or Set the serial interface auto printing interval. Where “n” is an integer value from 0-60. If “n” is 0, the auto print will be disabled. Values range from 1 to 60 and are in seconds. If “n” is left blank, the command will be treated as a query. This query responds with the command string “sa” and a Colon followed by the interval setting.

Read Example: sa

sa: 5

Set Example: s 10

### **t**

Read the control temperature in °C or °F (based on current system units). This command is query only and responds with the command string and a Colon followed by the temperature and associated units. Refer to SOUR:SENS:DAT command.

Read Example: t

t: 99.988 C

### **u[n]**

Read or Set the display temperature units, where “n” is a character “C” or “F”. Default: C If “n” is left blank, the command will be treated as a query. This query responds with the command string “u” and a Colon followed by the unit setting. Refer to UNIT:TEMP command.

Read Example: u

u: C

Set Example: u F

## 7 Troubleshooting

This section contains information on troubleshooting.

In the event that the Field Temperature Block appears to function abnormally, this section may help to find and solve the problem. Several possible problem conditions are described along with likely causes and solutions. If a problem arises, please read this section carefully and attempt to understand and solve the problem. If the Field Temperature Block seems faulty or the problem cannot otherwise be solved, contact an Authorized Service Center for assistance. Be sure to have the instrument model number, serial number, and voltage available.

**Table 8** *Troubleshooting, problems, causes and solutions*

Problem	Causes and Solutions
The instrument does not power up	<p>Check the fuses. If a fuse blows, it may be due to a power surge or a component failure. Replace the fuse once. DO NOT replace the fuse with one of a higher current rating. Always replace the fuse with one of the same rating, voltage, and type. If the fuse blows a second time, it is likely caused by failure of a component part.</p> <p>Check if the circuit breaker has tripped. Press the button to reset the circuit breaker. If the circuit breaker continues to trip repeatedly, there is likely a failure of a component part. Contact an Authorized Service Center.</p> <p>Power Cord. Check that the power cord is plugged in and connected to the instrument.</p> <p>AC Mains Power. Insure the circuit supplying power to the instrument is on.</p>
The display is blank The instrument powers up: FB150 – fan turns on, FB350 and FB660 – the power relay clicks, but the display remains blank	<p>Contrast. Check the screen contrast. Toggle the down arrow key to see if the screen contrast lightens.</p> <p>If the contrast is not the issue, contact an Authorized Customer Service Center.</p>
The instrument heats slowly	Scan Rate. Check the Scan Rate settings. The Scan Rate may be set with too low a rate per minute for the current application.
If the display shows an abnormal temperature	The sensor is disconnected, open or shorted. Please contact a Service Center for further instructions.
If the display shows cutout	<p>Cutout. If the Temperature Block exceeds the temperature set in the soft cutout menu, or if it exceeds the maximum operating temperature of the instrument, a cutout condition occurs. If this happens, the unit enters cutout mode and will not actively heat or cool until the user issues the command to clear the cutout or resets the instrument using the SET PT. key to clear the cutout mode and activate the instrument.</p> <p>Reset. The software cutout may need to be adjusted for the application. Check and adjust the cutout setting by entering CUTOUT menu: MENU/TEMPSETUP/CUTOUT.</p>

## FBXXX Field Temperature Block

Problem	Causes and Solutions
Temperature readout is not the actual temperature of the well OR Incorrect temperature reading	<p>Operating Parameters. Insure that all operating parameters for the Temperature Block, reference thermometer, and/or probe parameters match the Report of Certification that was sent with the instrument and/or probe.</p> <p>Electrical Interference. Look for sources of electrical interference, such as motors, welders, generating equipment nearby, or ground loops. Try shielding wires, removing ground loops, or changing location.</p>
(FB150) Probes stuck in the well at low temperatures	Moisture. If the Temperature Block has been used at low temperatures for extended periods of time, moisture may have built up in the well forming ice at low temperatures. Set the temperature high enough to melt ice to remove probes. Set the set-point to +100°C and allow the moisture to evaporate out of the system.
(FB150) Insert stuck in well	<p>If maintenance has not been performed on the insert as described in the Maintenance Section and the insert cleaned periodically, hard water build-up on the insert may cause it to stick.</p> <p>Have the unit in a cold environment – less 21°C. Set the unit to 100°C. While the unit is heating, at approximately 50°C to 70°C, pull on the insert.</p> <p>If this does not remove the insert, contact an Authorized Service Center.</p>
<b>-R Model Only</b>	
The Ref Probe shows an abnormal temperature or “.....”	Check the Probe type setting in the Reference Probe Setup menu is correct. Check all associated parameters. Check that the 4 probe wires are connected and not shorted inside of the connector.

## 8 Maintenance

The Field Temperature Block has been designed with the utmost care. Ease of operation and simplicity of maintenance have been a central theme in the product development. With proper care, the instrument should require very little maintenance. Avoid operating the instrument in an oily, wet, dirty, or dusty environment. Operating the instrument in a draft-free environment facilitates improved performance of the instrument.

- If the outside of the instrument becomes soiled, it may be wiped clean with a damp cloth and mild detergent. Do not use harsh chemicals on the surface which may damage the paint or plastic.
- It is important to keep the well of the block clean and clear of any foreign matter. **DO NOT** use fluid to clean out the well.
- The instrument should be handled with care. Avoid knocking or dropping the block.
- The removable inserts can become covered with dust and carbon material. If the buildup becomes too thick, it could cause the inserts to become jammed in the wells. Avoid this build up by periodically buffing the inserts clean.
- If an insert should be dropped, examine the insert for deformities before inserting it in the well. If there is any chance of jamming the insert in the well, file or grind off the protuberance.
- **DO NOT** allow the probe stems to drop into the well or harshly impact the well bottom. This type of action can cause a shock to the sensor.
- If a hazardous material is spilled on or inside the instrument, the user is responsible for taking the appropriate decontamination steps as outlined by the national safety council with respect to the material.
- If the mains supply cord becomes damaged, replace it with a cord of the appropriate gauge wire for the current of the instrument. If there are any questions, contact an Authorized Service Center for more information.
- Before using any cleaning or decontamination method, other than those recommended by Beamex, users should check with an Authorized Service Center to insure the proposed method will not damage the equipment.
- If the instrument is used in a manner not in accordance with the equipment design, the operation of the instrument may be impaired or safety hazards may arise.
- The over-temperature cutout should be checked every 6 months to see that it is working properly. In order to check the user selected cutout, follow the controller directions for setting the cutout. Set the instrument temperature higher than the cutout. Check to see if the display shows cutout and the temperature is decreasing.

### 8.1 Field Temperature Block Performance Analysis

For optimum performance and lowest possible uncertainty budgets, use the guidelines set forth below.

**Accuracy Drift**

The display temperature of the instrument will drift over time. This is due to a variety of factors affecting the temperature control PRT. Any PRT is subject to changes depending on how it is used and the environment it is used in. This is no different for any PRT in a calibration application. In addition, manufacturing variables in the sensing element itself can result in greater or lesser impact from use and environment. Oxidation and contamination from the sensor's environment will create changes requiring new calibration constants depending on the temperature range and normal operation of the instrument. Oxidation and contamination are generally not factors when Field Temperature Blocks are used exclusively below 200°C. Oxidation can form in the body of the PRT platinum sensor wire in the range of 300 °C to 500 °C. Contamination is primarily a problem following prolonged use above 500°C. Additionally, vibration from handling or transportation will strain the delicate PRT element, changing its resistance. Some of this strain may come out by annealing at a slightly higher temperature than the instrument is typically used at. It is recommended to avoid unnecessary temperature cycling. Cycling the temperature up and down between minimum and maximum temperatures excessively may also cause strain on the PRT element.

Effects from control sensor drift may be avoided by using an external temperature reference. In the case that the calibration of the display value is required, a program of monitoring and recalibration must be implemented, just as with any calibration standard. Regularly check the accuracy of the Field Temperature Block with an adequate temperature reference and keep records as a part of your instrument maintenance routine. When the accuracy drifts to a point where it is no longer acceptable, then have the instrument recalibrated. Your records will provide data for determining a calibration interval appropriate for your history of use and accuracy requirements.

**Stability**

The stability specification of the Field Temperature Block was determined under laboratory conditions of steady ambient temperature and air flow. While this instrument has been designed to minimize ambient effects, they will still have some effect. For the best results, avoid quickly-changing ambient temperatures and drafty conditions.

**Axial Uniformity**

Field Temperature Block axial uniformity should be checked periodically. Use the process outlined in EURAMET/cg-13/v.01 or a similar process. If the axial uniformity has changed outside the limits set by the user's uncertainty budget, adjustment of the axial gradient may be undertaken by trained personnel.