



# Quick guide to LOGiCAL



1 Activate your LOGiCAL account and sign in:  
[logical.beamex.com](http://logical.beamex.com)



2 Download the LOGiCAL Client:  
[logical.beamex.com/download/client/](http://logical.beamex.com/download/client/)



3 Install the LOGiCAL Client on the computer you connect your calibrator to  
**(administrator privileges required).**



4 Connect your calibrator to your computer with a USB cable



5 Start The Logical Client from Start-menu.  
Press **Authenticate** to sign in with the LOGiCAL account username and password



6 Configure Regional Settings in LOGiCAL Settings



7 Select your client and calibrator from the Calibrations section on the LOGiCAL site  
Select your results and press **Preview**



8 Download Certificate